


# Keys and Cores

Cores C | Keys A | Cormax | Cormax+

Service Manual



**T35527\_D** - 12/2024 Original document

ΕN

# **Credits and copyright**

Copyright ®2024 dormakaba USA Inc. All rights reserved.

Information in this document is subject to change without notice and does not represent a commitment on the part of dormakaba USA Inc. The software described in this document are furnished under a license agreement or nondisclosure agreement.

This publication is intended to be an accurate description and set of instructions pertaining to its subject matter. However, as with any publication of this complexity, errors or omissions are possible. Please call dormakaba USA Inc. at 1-800-392-5209 if you see any errors or have any questions. No part of this manual and/or databases may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or information storage and retrieval systems, for any purpose, without the express written permission of dormakaba USA Inc.

This document is distributed as is, without warranty of any kind, either express or implied, respecting the contents of this book, including but not limited to implied warranties for the publication's quality, performance, merchantability, or fitness for any particular purpose. Neither dormakaba USA Inc., nor its dealers or distributors shall be liable to the user or any other person or entity with respect to any liability, loss, or damage caused or alleged to be caused directly or indirectly by this publication.

#### dormakaba USA Inc.

6161 E. 75th St. Indianapolis, IN 46250

T35527\_Rev D B1823547 ER7991-6 Dec 2024

# **Contents**

1	Getting started	5
1.1	Introduction	5
1.2	Core and Key product family diagram	5
1.3	Documentation package	E
1.4	Technical support	6
2	Parts	7
2.1	Overview of BEST core	7
2.2	BEST Standard and premium cores ordering table	8
2.3	BEST Cormax M series ordering table	8
2.4	BEST Cormax X series ordering table	8
2.5	Cormax+ X series ordering table	S
2.6	Cormax+ M series ordering table	9
2.7	Overview of BEST cores	10
2.8	Overview of Cormax and Cormax+ cores	1 1
2.9	Core options	12
2.10 2.11	Segments, springs, and caps UL application of 5C, 5 CM, 5 CMP, 5 CXP core	1 3 1 4
2.11	Overview of BEST standard and thick key	1 5
2.13	BEST standard and premium keys table	1 6
2.14	BEST Cormax M series key table	1 6
2.15	BEST Cormax X series key table	1 6
2.16	BEST Cormax+ X series key table	1 7
2.17	BEST Cormax+ M series key table	1 7
2.18	Key type descriptions	1.8
2.19	Key stamp options and descriptions	1 9
3	Tools	20
3.1	Tools for servicing cores and keys	20
3.2	Stamping tools	2 1
3.3	Lubrication items	2 1
4	Servicing	22
4.1	Placing pin segments, spring, and caps in a core	2.2
4.2	Loading core	23
4.3	Inserting ejector pin	23
4.4	Inserting segments into barrel	23
4.5 4.6	Inserting stop pin and core into capping block	2 4
4.0	Seating cap in barrel Special guidelines	2 4 2 4
4.7	Checking a core for proper operation	2.5
4.9	Replacing dust cover assembly	2.5
4.10	Lubricating a core	2.5
4.11	Thawing a core	2 5
5	Troubleshooting	26
5.1	Causes and solutions for common problems	26
5.2	Performing thumb check procedure	28
5.3	Using key cut indicator	2.8
6	Documentation	2.8

# **Figures**

1	Getting started	5
	Key combinator	5
	Combinating kit	5
	Core	5
	Core capping press	5
	Key	5
2	Parts	7
	1 C core	10
	1 CCOBP core	10
	3C core	10
	1 CP core	10
	2C core	10
	5C core	10
	Cormax core	11
	Cormax+ core	11
	Cormax 5C core  Cormax+ 5CMP & CXP core	11
		11
	Segments, springs, and caps	13
	Loading 5C core for 1E7K 4 cylinder Standard key features	1 4 1 5
	Thick key features	15
	1A key	18
	1AP key	18
	2A key	18
	3A key	18
	4A key	18
	9A blockout blade	18
	Thick keys	18
	KS654 key stamp	19
	KS 567 key stamp	19
	Cormax standard key stamp	19
	Cormax+ standard key stamp	19
	KS292 key stamp	19
	KS594 key stamp	19
	Cormax thick key stamp	19
	Cormax+ X series key stamp	19
	Tools used for servicing cores and keys	20
3	Tools	20
	Stamping tools	21
	Lubrication items	21
4	Servicing	22
	ldentifying parts of core	23
5	Troubleshooting	26
	Using key cut indicator	28
	Using ejector pin to mark segment stack height	28
6	Documentation	28


# 1 Getting started

### 1.1 Introduction

The Key and Core Service Manual contains essential information to assist with the maintenance of BEST keys and cores.

# 1.2 Core and Key product family diagram

Fig. 1, Fig. 2, Fig. 3, Fig. 4, Fig. 5



### 1.3 Documentation package

#### Table 1

Documentation is available to help with installation, operation, and maintenance of BEST keys and cores along with associated service equipment. These documents can be ordered separately from product.

Documentation title	Doc no.
Installation Instructions for construction cores operating	T35526
Instructions for AD 432 key combinator operating	T35531
Instructions for AD 433 key combinator operating	T35529
Instructions for AD502 micrometer key gauge key	T35530
Combinator service manual	T35532
A2 system service manual	T35534
A3 system service manual	T35535
A 4 system service manual	T35536

### 1.4 Technical support

#### Support services:

When a problem occurs with a BEST core or key, the first resource for help is the Key and Core Service Manual. If a satisfactory answer cannot be found, contact a local dormakaba representative.

#### Call technical support:

A factory-trained Certified Product Specialist (CPS) is available whenever help is required.

Before calling, please make sure the product is in the immediate vicinity, and the following information is prepared:

- what happened and what was being done when the problem occured.
- what has been done to correct the problem.

dormakaba USA Inc. representatives provide telephone technical support for all B Series products. To locate the nearest representative, call 1-800-392-5209 Monday through Friday, between 8:00 a.m. and 5:00 p.m. eastern standard time; or visit the web page: https://dhwsupport.dormakaba.com/hc/en-us.


dormakaba holds training sessions for its customers. Seminars are specifically designed for dormakaba end-users who have a registered dormakaba [BEST branded product] masterkeyed system, and registered dormakaba [BEST branded product] security equipment. If interested, contact a local dormakaba representative for details.

# 2 Parts

The following pages contain descriptions and figures of cores, keys, and tools for servicing them.

### 2.1 Overview of BEST core

#### Fig. 6, Fig. 7



# 2.2 BEST Standard and premium cores ordering table

#### Table 2

Use the following table to assist with ordering a BEST standard and premium core.

Core type	Core size	Keyway	Combinating code	Options	Finishes
1 C – Standard	<b>7</b> – 7 -pin	Designate specific keyway (A, E, etc.)	1 – Uncombinated	Blank – Standard	6 0 5 – Bright brass
1 CP – Premium key system	<b>6</b> -6 -pin (10 & 20 cores only)		2 – Combinated	B— Pick & drill resistant	606 – Satin brass
1 CCOBP – Plastic construction core				<b>D</b> – Drill resistant	6 1 2 – Satin bronze
2C – Extended plug				<b>K</b> - Key trap	6 1 3 – Oxidized satin, bronze, oil rubbed
3C – European				<b>P</b> – Pick resistant	6 2 5 – Bright chromium plated
<b>5C</b> – High security				S- Set screw (6C only)	6 2 6 – Satin chromium plated
6C – Core for 4S				<b>W</b> – Wear resistant	

# 2.3 BEST Cormax M series ordering table

#### Table 3

Use the following table to assist with ordering an M series Cormax core.

Core Type	Core Size	Keyway	Level	Combinating Code	Options	Finish	
1 CM – CORMAX Core M series key	<b>6</b> –6-pin	MJ	1 –Non-exclusive	1 –Uncombinated	B*-Pick & drill resistant (1CDM combinated core only)	605	606
1 CDM—CORMAX Drill resistant (M series only)	<b>7</b> – 7 -pin	MK		<b>2</b> –Combinated	K*–Key trap ( 1CM only)	611	612
<b>5CM**</b> –CORMAX for High security (M series only)		ML	<b>3</b> –One digit zip code exclusive		P*–Pick resistant	613	625
<b>6CM</b> -CORMAX Core for 4S cylinder		ММ	4 – National exclusive		T*-Key retained [6 CM only]	626	690
					<b>W</b> *–Wear resistant		

<sup>\*</sup>Indicates extra cost option; see below

# 2.4 BEST Cormax X series ordering table

#### Table 4

Use the following table to assist with ordering an X series Cormax core.

Core Type	Core Size	Keyway	Level	Combinating Code	Options	Finish	
1 CX-CORMAX Core X Series	6-6-pin	XLX32, etc.	<b>W</b> -Non-exclusive	1 –Uncombinated	<b>B*</b> –Pick & drill resistant (1CDM combinated core only	605	606
1 CDX-CORMAX Drill resistant (X Series only)	7 – 7 -pin		X-Two-digit zip code exclusive	<b>2</b> -Combinated	<b>P*</b> -Pick resistant	611	612
6CX -CORMAX Core for 4S			<b>Y</b> –One digit zip code exclusive		<b>W</b> *–Wear resistant	613	625
			<b>Z</b> -National exclusive			626	690

<sup>\*</sup>Indicates extra cost option; see below

<sup>\*\*</sup>Only compatible with high security mortise cylinders

If combinated, you must specify keymark and number of keys

<sup>\*\*</sup>Only compatible with high security mortise cylinders

If combinated, you must specify keymark and number of keys

# 2.5 Cormax+ M series ordering table

#### Table 5

Use the following table to assist with ordering a Cormax+ M series core.

Core type	Core size	Keyway	Level	Combinating Code	Options	Finish	es
1 CMP-CORMAX+ core	<b>6</b> -6-pin	PMJ	1 –Non-exclusive	1 –Uncombinated		605	606
M series						611	612
1 CDMP-CORMAX+ drill resistant (M series only)	<b>7</b> –7-pin	PMK		<b>2</b> -Combinated	K*-Key trap ( 1CMP only)	613	618
<b>5CMP</b> –CORMAX+ for high		PML	<b>3</b> —One-digit zip		<b>P*</b> –Pick resistant	619	622
security (M series only)			code exclusive			625	626
<b>6CMP</b> -CORMAX+ core for 4S cylinder		РММ	<b>4</b> –One-digit zip code exclusive		T*-Key retained (6 CMP only)	690	
					<b>W</b> *–Wear resistant		

# 2.6 Cormax+ X series ordering table

#### Table 6

Use the following table to assist with ordering a Cormax+ X series core.

Core type	Core size	Keyway	Level	Cominating Code	Options	Finishe	s
1 CXP-CORMAX + core	<b>6</b> -6-pin	PX1,	<b>W</b> -Non-exclusive	1 –Uncombinated		605	606
X series		PX32,etc.				611	612
1 CDXP-CORMAX + Drill resistant (X series only)	<b>7</b> – 7 -pin		<b>X</b> –Two-digit zip code exclusive	<b>2</b> -Combinated (B Option)	<b>P*</b> –Pick resistant	613	618
5CXP-CORMAX + Core			<b>Y</b> –One digit zip code		<b>W</b> *–Wear resistant	619	622
for high security			exclusive			625	626
<b>6 CXP</b> -CORMAX + Core 4S cylinder			<b>Z</b> –National exclusive		T*-Key retained (6 CXP only)	690	

<sup>\*</sup>Indicates extra cost option; see below

<sup>\*\*</sup>Only compatible with high security mortise cylinders

If combinated, you must specify keymark and number of keys

### 2.7 Overview of BEST cores

Fig. 8, Fig. 9, Fig. 10, Fig. 11, Fig. 12, Fig. 13, Fig. 14

#### 1 C core


Standard interchangeable core.



Figure 8 1 C core

#### 1CCOBP core

Black plastic, non-keyed construction core used to secure interior doors at a construction site.



3C core

Interchangeable core used with 8E European lock adaptation.



Figure 12 3C core

#### 1 CP core

Premium interchangeable core.



Figure 9 1 CP core

#### 2C core

Interchangeable core used in 8L mailbox lock.



Figure 11 2C core

#### 5C core


High security interchangeable core used in 1E cylinder for mortise applications.



Figure 13 50 core

#### 6C core

Interchangeable core used in 4S sliding door cylinder lock. Regardless of core finish, lost-motion assembly on back of core has a stainless steel finish.



NOTE: Set screw style is not shown.

### 2.8 Overview of Cormax and Cormax+ cores

Fig. 15, Fig. 16, Fig. 17, Fig. 18

#### Cormax core

BEST patented small format interchangeable core.



Figure 15 Cormax core

#### Cormax+ core

BEST patented small format interchangeable core.



Figure 17 Cormax+core

#### Cormax 5CM core

High security Cormax core used in 1 E cylinder for mortise applications.



Figure 16 Cormax 5C core

#### Cormax+ 5CMP & 5CXP core

High security Cormax+ core used in 1 E cylinder for mortise applications.



Figure 18 Cormax+ 5 CMP & CXP core


# 2.9 Core options

### Table 7

Option	Nomenclature	Description
Pick & drill resistant	В	Provides enhanced resistance to picking and drilling the core. Hardened ball bearings are used in throw pin holes, and hardened stainless steel segments are used as top and bottom segments in first two barrels of core. Spooled segments are used as top and bottom segments in each remaining barrel of core.
Dust cover	С	Prevents keyway from accumulating dust and dirt. Stainless steel spring-loaded dust cover is installed over keyway. For part numbers, see <a href="mailto:page-25">page-25</a> .  NOTE: If core is housed in a cylinder, use cylinder dust cover instead of core dust cover for maximum protection.
Drill resistant	D	Provides enhanced resistance to drilling core. Hardened ball bearings are used in throw pin holes and hardened stainless steel segments are used as top and bottom segments in first two barrels of core.
Key trap	К	Eliminates a key from system by trapping it in core. This option is useful if a key has been lost, or if someone has a key and will not give it back. When key is inserted into core and is turned, key is trapped in core. Key cannot be returned vertically nor withdrawn from core. Core and trapped key must be drilled out of lock. This special core is modified at factory to match key wanting to be trapped.
Pick resistant	р	Provides enhanced resistance to picking core. Spooled segments are used as top and bottom segments in each barrel of core.
Set screw (for 6C core only)	S	Alternate design of $6\mathrm{C}$ core used in $4\mathrm{S}$ sliding door cylinder lock. A set screw is used to hold core in lock.
Key retained (for 6C core only)	Т	Provides an extra measure of security by trapping key in core while core is unlocked. Core stays locked unless key is left in it. A sleeve without a slot is used to hold key in core.
Wear resistant	W	Provides longer life for cores in high traffic areas. Hardened stainless steel segments are used as bottom segments in each barrel of core.

# 2.10 Segments, springs, and caps

### Fig. 19



Item	System	Nomenclature	Description					
1	A2	А						
	АЗ	С	Standard beveled (bottom) segment.  Available in nickel silver or hardened stainless steel.					
	Α4	Е	Available if filence silver of filal defled stailliess steel.					
2	A2	В						
	АЗ	D	Standard flat (top) segment.  Available in brass or hardened stainless steel.					
	Α4	F	Available ii bi ass of flat defled stairliess steel.					
3	A2	А						
	АЗ	С	Spooled beveled (bottom) segment.  Available in nickel silver.					
	Α4	Е	- Available III Herica Gilver.					
4	A2	В						
	АЗ	D	Spooled flat (top) segment.  Available in brass					
	Α4	F						
5		22S 22S20M	Spring (500 per package) Spring (20,000 per package)					
6		210	Cap (500 per package)					

NOTE: For more information, see A2 System Service Manual (T35534), A3 System Service Manual (T35535), and A4 System Service Manual (T35536).

### 2.11 UL application of 5C, 5CM, 5CMP, 5CXP core

#### Fig. 20


5C, 5CM, 5CMP, or 5CXP core is used in 1E7J4 and 1E7K4 high-security cylinders. They are also used in 71B, 81B, and 91B high-security padlocks.

To have 1E7J4 cylinder qualify for Underwriters Laboratories (UL) high-security rating, 5C, 5CM, 5CMP, or 5CXP core must be combinated and loaded at factory. Likewise, any core that needs to be recombinated and reloaded must be sent to factory. If 5C, 5CM, 5CMP, or 5CXP core is combinated and loaded outside of factory, cylinder no longer qualifies for UL rating, and UL-stamped cylinder faceplate cannot be used.

1E7K4 cylinder does not have UL-stamped faceplate. You can combinate and load 5C, 5CM, 5CMP, or 5CXP core to be used in a 1E7K4 cylinder.


For high-security applications, combinate and load 5C, 5CM, 5CMP, or 5CXP core as you would any other core with these exceptions:

- · Use hardened stainless steel segments in barrels six and seven.
- Use spooled segments in all remaining barrels, except where 6B segments are required.
   In those cases, use standard 6B segments.



# 2.12 Overview of BEST standard and thick key

#### Fig. 21, Fig. 22



# 2.13 BEST standard and premium keys table

#### Table 8

Use the following table to assist with ordering a BEST Cormax M series key.

Key shape (bow)	Key type	Keyway	Cut code	Key stamp	Options
<b>1 A</b> -Standard	<b>0</b> –Blockout blade	Designate specific	<b>1</b> –Blank	KS654 x KS292- Standard embossing supplied if not designated.	<b>B</b> *-Long blade (1 A only)
<b>1 AP</b> –Premium	<b>1</b> –Operating or blank	keyway (A, E, etc) or multiple	<b>2</b> -Cut		H*-No hole (2A only)
2A-Large round	<b>2</b> -Control	keyways if		KS 112 – "US. Gov't do not duplicate"	N*-Long nose (1 A only)
<b>3A</b> –Large rectangular	3-Master	ordering a multi-milled kev.		KS657 – Premium	<b>NKW</b> –No keyway designation (standard on 1 AP)
4A-Access bow	<b>4</b> -Submaster	icy.			S*–Key serialization
<b>9A</b> –Blockout blade	<b>5</b> -Gradmaster			Specify KS#. Price for most custom	
	<b>9</b> –Extractor key			design stamps available upon request.	

<sup>\*</sup>Indicates extra cost option; see below

### 2.14 BEST Cormax M series key table

#### Table 9

Use the following table to assist with ordering a BEST Cormax M series key.

Key shape (bow)	Key type	Keyway	Level	Cut code	Key stamp	Options
<b>1 AM</b> – M series key	<b>0</b> -Blockout blade	MJ MK ML MM	1 –Non-exclusive	<b>1</b> –Blank	KS716-1 AM Front	<b>B*</b> –Long blade ( 1 AM series only)
2AM-Large round	1 –Operating or blank			<b>2</b> -Cut	<b>KS800</b> – 1 AM Back	<b>H*</b> –No hole (2AM series only)
<b>3AM</b> -Large rectangular	<b>2</b> –Control		<b>3</b> –One digit zip code exclusive			N*–Long nose ( 1 AM series only)
4AM-Access bow	<b>3</b> -Master		<b>4</b> -National			S*–Key serialization
<b>9AM</b> –Blockout blade	<b>4</b> -Submaster					
	<b>5</b> -Gradmaster					
	<b>9</b> –Extractor key					

<sup>\*</sup>Indicates extra cost option; see below

# 2.15 BEST Cormax X series key table

#### Table 10

Use the following table to assist with ordering a BEST Cormax X series key.

Key shape (bow)	Key type	Keyway	Level	Cut code	Key stamp	Options
1 AX-X series key	<b>0</b> -Blockout blade	XLX32, etc.	<b>W</b> -Non-exclusive	<b>1</b> –Blank	<b>KS717</b> – 1 AX Front	S*–Key serialization
9AX-Blockout blade	<b>1</b> –Operating or blank		<b>X</b> —Two-digit zip code exclusive	<b>2</b> -Cut	KS699-1 AX Back	
	<b>2</b> -Control		<b>Y</b> –One digit zip code exclusive			
	<b>3</b> -Master		<b>Z</b> –National			
	<b>4</b> -Submaster					
	<b>5</b> -Gradmaster					
	<b>9</b> -Extractor key					

<sup>\*</sup>Indicates extra cost option; see below

If keys are cut, you must specify keymark and number of each marking.

a. You must designate a front key stamp and a back key stamp. There is no standard back key stamp for Premium key.

If keys are cut, you must specify keymark and number of each marking.

a. You must designate a front key stamp and a back key stamp. There is no standard back key stamp for Premium key.

b. B-Long blade available on 1 AM series only.

If keys are cut, you must specify keymark and number of each marking.

a. You must designate a front key stamp and a back key stamp. There is no standard back key stamp for Premium key.

# 2.16 BEST Cormax+ M series key table

#### Table 1 1

Use the following table to assist with ordering a BEST Cormax+ M series key.

Key shape (bow)	Key type	Keyway	Level	Cut code	Key stamp	Options
<b>1 AMP</b> – M series key	<b>0</b> -Blockout blade	PMJ PMK PML PMM	1 –Non-exclusive	<b>1</b> –Blank	KS768- 1 AMP Front	<b>B*</b> –Long blade ( 1 AMP series only)
2AMP-Large round	<b>1</b> –Operating or blank		2-Two-digit zip code exclusive	<b>2</b> -Cut	KS800-1 AMP Back	H*-No hole (2 AMP series only)
<b>3AMP</b> –Large rectangular	<b>2</b> –Control		<b>3</b> –One digit zip code exclusive			N*–Long nose (1 AMP series only)
4AMP-Access bow	<b>3</b> -Master		<b>4</b> -National			S*–Key serialization
<b>9AMP</b> –Blockout blade	<b>4</b> -Submaster					
	<b>5</b> -Gradmaster					
	<b>9</b> –Extractor key					

<sup>\*</sup>Indicates extra cost option; see below

# 2.17 BEST Cormax+ X series key table

#### Table 12

Use the following table to help with ordering a BEST Cormax+ X series key.

Key shape (bow)	Key type	Keyway	Level	Cut code	Key stamp	Options
1 AXP- X series key	<b>0</b> -Blockout blade	PX1,	<b>W</b> -Non-exclusive	<b>1</b> –Blank	KS767- 1 AXP front	S*–Key serialization
9 AXP-Blockout blade	<b>1</b> –Operating or blank	PX32, etc.	<b>X</b> –Two-digit zip code exclusive	<b>2</b> -Cut	KS699- 1 AXP back	B*-Long blade ( 1 AXP series only)
	<b>2</b> -Control		<b>Y</b> –One digit zip code exclusive			N*–Long nose ( 1 AXP series only)
	<b>3</b> -Master		<b>Z</b> –National			
	<b>4</b> -Submaster					
	<b>5</b> -Gradmaster					
	<b>9</b> –Extractor key					

<sup>\*</sup>Indicates extra cost option; see below

If keys are cut, you must specify keymark and number of each marking.

If keys are cut, you must specify keymark and number of each marking.

a. You must designate a front key stamp and a back key stamp. There is no standard back key stamp for Premium key.

b. B-Long blade available on 1 AMP series only.

a. You must designate a front key stamp and a back key stamp. There is no standard back key stamp for Premium key.


b.  $\,\,$  B-Long blade available on 1 AXP series only.

# 2.18 Key type descriptions

# Fig. 23, Fig. 24, Fig 25, Fig. 26, Fig. 27, Fig. 28, Fig. 29 1 A key Standard key with standard bow. Standard Long blade Long nose Figure 23 1A key


#### 1 AP key

Premium key used with 1 CP core.



2A key

Standard key with round bow.



3A key

#### Standard key with a rectangular bow.




Figure 26 3A key

#### 4A key

Standard key with large offset bow. Comes with or without a window. Used with hotel locks.




Figure 27 4A key

#### 9A blockout blade and 9A9 blockout blade extractor

9A blockout blade slides in a keyway and blocks out other keys. 9A9 is a special tool used to remove 9A blockout blade segment.



9A blockout blade extractor key (included with 9A blade)



Figure 28 9A blockout blade

#### Thick key

Thicker key and larger bow.





Figure 29 Thick keys

### 2.19 Key stamp options and descriptions

Fig. 30, Fig. 31, Fig. 32, Fig. 33, Fig. 34, Fig. 35, Fig. 36, Fig. 37



a. There is no standard back key stamp for 1AP premium key.


# 3 Tools

# Tools for servicing cores and keys

Fig. 38

Item	Nomenclature	Description
1	AD433	Key combinator <sup>a,b</sup>
2	CD517	Core capping press
3	CD433	Combinating bin
4	DD550	Combinating hammer
not shown	DD 551	Plastic heads for combinating hammer
5	CD431	Complete combinating kit <sup>b</sup>
6	CD540	Capping block <sup>c</sup>
7	CD548	Ejector pin <sup>c</sup>
8	CD549	Tweezers <sup>c</sup>
9	CD547	Hand capping pin <sup>c</sup>
10	AD501	Key cut indicator <sup>b,c</sup>

- a. For other parts associated with key combinator, see Key Combinator Service Manual.
- b. Specify A2, A3, or A4 Keying System when ordering.
  c. Also is included in the complete combinating kit (CD 4 3 1).




# 3.2 Stamping tools

Fig. 39

em Nomen	clature	Description		
CD504	+ C	Core stamping plate-side only (for 5 0 cores)		
CD504	B	Core stamping plate-face only (for 8 7 cores)		
DD514		Core/key marking plate		
AD504	ŀΑ	Key stamping plate (for keys)		
DD513	}	Core/key marking block		
DD503	}	Number dies (1/16" or 3/32")		
DD 5 1 4	ŀΑ	Magnetic strip <sup>a</sup>		
DD502	)	Letter dies (1/16" or 3/32")		
A set of 3 is included	with the core/k	sey marking plate (DD 5 1 4)	-	<b>39</b> Stampir
A set of 3 is included	with the core/k	sey marking plate (DD 5 1 4)	Figure 2	<b>39</b> Stamp
A set of 3 is included	with the core/k	sey marking plate (DD 5 1 4)	-	<b>39</b> Stamp
A set of 3 is included	with the core/k	sey marking plate (DD 5 1 4)	-	39 Stamp
A set of 3 is included	with the core/k	tey marking plate (DD 5 1 4)	2	39 Stamp
A set of 3 is included	with the core/k	sey marking plate (DD 5 1 4)	2	39 Stamp
set of 3 is included		tey marking plate (DD 5 1 4)	2	39 Stam
of 3 is included		tey marking plate (DD 5 1 4)	2	339
set of 3 is included		tey marking plate (DD 5 1 4)	2	39

# 3.3 Lubrication items


Fig. 40



# 4 Servicing

# 4.1 Placing pin segments, spring, and caps in a core

Fig. 4 1



### 4.2 Loading core

#### Fig. 42

To determine specific sequence of segments to place in each core, refer to Masterkey Code Sheet and Combinating Instruction Sheet supplied by dormakaba.

#### NOTE: For information about loading cores used for UL applications, see page 14.

4.2.1 Before starting, identify parts of core you will be working with. Front of core is identified by BEST logo. Barrel number one is at back of core.




Figure 42 Identifying parts of core

#### 4.3 Inserting ejector pin

#### Fig. 43

- 4.3.2 Insert ejector pin into notch on back of sleeve. Push control lug into thrown (extended) position. Remove ejector pin from notch.
- 4.3.3 Insert ejector pin into cavity between lug and core body to hold lug in thrown position. Use your thumb and forefinger to rotate core plug until keyway is straight up and down, and bottom of keyway is in six o'clock position. Remove ejecgtor pin from cavity.
- 4.3.4 Insert ejector pin into barrel number seven to ensure barrels stay aligned. Leave ejector pin inserted and perform next step.




Figure 43 Pushing control log into thrown position

#### 4.4 Inserting segments into barrel

#### Fig. 4 4

- 4.4.5 Use your combinating instruction sheet to determine what segments are required for barrel number one. Insert bottom segment, beveled end down, into barrel number one.
- 4.4.6 Remove ejector pin from barrel number seven and use it to tap down segment until it seats at bottom of barrel. You should see segment protruding into keyway.
- 4.4.7 Insert next required segment into barrel number one. Use ejector pin to tap down segment until it is seated.
- 4.4.8 Repeat step 5 through step 7 until all required segments are loaded into all barrels.




Figure 44 Inserting segments into barrel

### 4.5 Inserting stop pin and core into capping block

#### Fig. 45

4.5.1 Insert stop pin into appropriate hole in side of capping block to align core barrels with holes in capping block.

NOTE: Do not cut the segment springs and insert an extra cap.

4.5.2 Insert core into capping block.





Figure 45 Inserting stop pin and core into capping block

### 4.6 Seating cap in barrel

#### Fig. 46

- 4.6.1 Insert a spring into barrel number one. Place a cap over the barrel.
- 4.6.2 Insert capping tool into barrel number one. Use a hammer to tap capping tool and drive down cap until bottom of capping tool hits top of capping block.
- 4.6.3 Repeat step 11 and step 12 until all barrels are capped.
- 4.6.4 Test all keys (including control, grandmaster and operating keys) in core to ensure each barrel is loaded correctly.



NOTE: If a barrel is not loaded correctly, insert ejector pin through ejector holes and tap out segments, spring, and cap. Discard used segments, spring, and cap, and reload barrel.

# 4.7 Special guidelines

#### When stamping and loading core, follow guidelines below:

- 4.7.1 If core is not operating smoothly while you are loading it, do not tap core against a metallic block. Use a block made of nylon or an equivalent material.
- 4.7.2 Do not use a metal-headed hammer on cores. Use a plastic-headed hammer only.
- 4.7.3 Do not use excessive force to stamp core markings on side of cores. Excessive force may cause barrel opening to close slightly.
- 4.7.4 Do not stamp core on bottom lobe.
- 4.7.5 Do not enlarge segment holes. This may cause problems with segment capping.


### 4.8 Checking a core for proper operation

- 4.8.1 Periodically test all of your keys, including control, grandmaster, and operating keys in core to make sure core is operating properly.
- 4.8.2 Insert a key in the core. If you can insert, turn, and remove the key easily, core and key are working properly. If not, see troubleshooting section on page 2.5.

### 4.9 Replacing dust cover assembly

#### Fig. 47

- 4.9.1 Unscrew screw and remove dust cover and dust cover hinge.
- 4.9.2 Place dust cover over key hole in core so lip faces away from core. Place dust cover hinge on face of core with prongs covering dust cover, as shown in Figure 47.
- 4.9.3 Install screw.



# 4.10 Lubricating a core

Create a preventive maintenance plan that includes lubricating the core. To extend the life of the core, lubricate it regularly. Powdered graphite is the best choice for lubrication.



CAUTION! Do NOT lubricate a core with oil. Doing so will attract dirt.



CAUTION! Do not mix graphite with liquid lubricant.

#### For powdered graphite lubrication:

- 4.10.1 Remove core from lock.
- 4.10.2 Dip a key in graphite. With core inverted, insert key into keyhole and remove it; repeat several times, allowing graphite to penetrate the barrels.

OR

With core inverted, spray graphite into keyhole. Insert key into keyhole and remove it; repeat several times, allowing graphite to penetrate barrels.

# 4.11 Thawing a core

If core is frozen, use following techniques to thaw it:

- Heat key and insert it into core.
- Spray a commercial lock antifreeze or ice dissolver into core.



CAUTION! Do not heat core with a propane torch. This will cause internal damage and possibly cause core to become inoperable.

# 5 Troubleshooting

# 5.1 Causes and solutions for common problems

This table summarizes possible causes for most common core and key problems. Causes are listed in order of likelihood, with most likely cause first.

You notice	Possible causes include	You should
It is difficult to insert or remove key.	Key's keyway is not compatible with core.	Look at the end of the key and the keyway of the core. If profiles do not match, check your Masterkey Specification to see what type of keyway must be used with core.
	Key is damaged.	Check key to see whether it has been damaged. If it has, replace key.
	There is foreign material on key or in keyway of core.	Check key and keyway of core for foreign material. If there is foreign material, remove it with compressed air or LPS lubricant.
	Keyway of core has been damaged.	Check keyway of core for damage. If it is damaged, contact your dormakaba Representative.
	Barrels of core are not loaded correctly.	Check inside keyway to see whether ends of bottom segments that protrude into keyway are flat or beveled. If any of bottom segments appear to be inserted incorrectly, reload that barrel with new segments, spring, and cap. Make sure beveled end of bottom segment is inserted first into barrel.
		<ol> <li>Perform the thumb check procedure to see whether the height of any segment stack varies. (see page 26).</li> </ol>
		If problem still is not solved, check Masterkey     Specification for errors. Reload core and cut new keys     as necessary.
	Caps are inserted too deeply into barrels	From top of core, look into barrels, or use a depth gauge to see whether one or more caps is inserted more deeply into barrel. [Correct cap depth is .0 2 5 to .0 4 0 inches from top of core.] If so, reload barrel with new segments, spring, and cap.
Key does not rotate core plug or control lug.	Key is cut improperly.	Use key cut indicator to determine whether key was cut correctly (see page 26).  If key cuts are not correct, cut a new key.
	Barrels of core are not loaded correctly.	Reload core with new segments, springs, and caps. If key still does not rotate, check Masterkey Specification for errors.
	K ey combinator needs to be recalibrated.	If you cut a new key and you are still having problems, Key Combinator may need to be recalibrated. See Key Combinator Service Manual.


You notice	Possible causes include	You should
Key does not rotate smoothly.	Key is cut improperly.	Use key cut indicator to determine whether key was cut correctly. (see page 26).  If key cuts are not correct, cut a new key.
	Barrels of core are not loaded correctly.	Check inside keyway to see whether ends of bottom segments that protrude into keyway are flat or beveled. If any bottom segments appear to be inserted incorrectly, reload that barrel with new segments, spring, and cap. Make sure beveled end of the bottom segment is inserted first into barrel.
		<ol><li>Perform thumb check procedure to see whether height of any segment stack varies. [see page 26].</li></ol>
		3. If problem still is not solved, check Masterkey Specification for errors. Reload core and cut new keys as necessary.
	Key combinator needs to be recalibrated.	If you cut a new key and you are still having problems, Key Combinator may need to be recalibrated. See Key Combinator Service Manual.
Core does not insert into	Core lug is not fully retracted.	Check behind the lug for any foreign material. Clean it as necessary.
cylinder/ receptacle.	Throw pins inside receptacle are not aligned with holes in core.	Check to see whether throw pins are out of alignment. Use a screwdriver to align throw pins with throw pin holes in core.
	There is foreign material in cylinder/receptacle.	Check cylinder/receptacle for foreign material. Clean it as neccessary
	For mortise locks only, cylinder set screw is installed too tightly.	Remove mortise case faceplate and loosen cylinder set screw.
Cormax+ blocking feature missing.	Using Cormax key in Cormax+ core before installing	Contact Customer Support.
Ejecter pin or decapping block pin will not go in barrel 2 from the knockout hole.	Using an ejector pin or decapping block that is too large.	Use a smaller pin (<0.052") or contact customer support.

### 5.2 Performing thumb check procedure

#### Fig. 48

# Perform following steps to check each barrel of core to make sure segment stacks are of equal height:


- 5.2.1 Insert ejector pin into number one ejector hole.
- 5.2.2 Use your thumb to mark depth on ejector pin. Keep your thumb in place.
- 5.2.3 Insert pin into other ejector holes. If segment stack height varies, use ejector pin to force out segments, springs, and caps of barrels that are incorrectly loaded. Discard used segments, springs, and caps. Reload barrels with new segments, springs, and caps.



### 5.3 Using key cut indicator

#### Fig. 49

- 5.3.1 Insert your key into the key cut indicator that is appropriate for your keying system, with key cuts facing numbers on key cut indicator.
- 5.3.2 Slide key until it contacts indicator at the top and bottom. Read the key cut number that aligns with position of key.
- 5.3.3 Make sure that key cut corresponds to key cut for that position listed on your Masterkey Specification. If key cut does not match what is listed, cut a new key.
- 5.3.4 Repeat step 1 through step 3 for each key cut on your key.



# 6 Documentation

All technical documentation, including all Key and Core service manuals, can be found on the Knowledge Base: <a href="Cores"C" & Keys "A" Series">Cores "C" & Keys "A" Series</a>

For additional product details, downloads, and warranty information, please visit: https://dhwsupport.dormakaba.com/hc/en-us/



Scan for product details and downloads.

Call 1-800-392-5209 or visit https://dhwsupport.dormakaba.com/hc/en-us for assistance and warranty information.