

**Door Closer Models: SL6014, SL6036 SPA, SPAT x FTHD Super Parallel Arm Flush Transom Installation [Push Side Mount] with Plate DP60 Drilling Instructions**

For online instructions, assistance or warranty information:  
Call 1-800-392-5209 or visit <https://dhwsupport.dormakaba.com/hc/en-us>

**NOTES:**

1. DO NOT SCALE DRAWING.
2. DIMENSIONS ARE IN INCHES/[MM].
3. LEFT HAND DOOR SHOWN.
4. CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACED COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
5. MINIMUM DOOR WIDTH 26"
6. TEMPLATING BASED ON 4-1/2" x 2-1/2" BUTT HINGES.
7. DPK FASTENERS FOR STEEL DOOR & FRAME ONLY.

| ANGLE OF OPENING HOLD OPEN | DIM. "C" PLATE  | DIM. "B" FTHD BRACKET |
|----------------------------|-----------------|-----------------------|
| TO 100°<br>H.O. 90°        | 9-3/8"<br>[238] | 10-1/8"<br>[257]      |
| TO 180°<br>H.O. 123°       | 5-3/4"<br>[146] | 6-1/2"<br>[165]       |

