## Door Closer Models: SL6014, SL6036 S-IS & S-ISH (Dead Stop Arm) Regular Installation (Pull Side Mount) Drilling Instructions



For online instructions, assistance or warranty information: Call 1-800-392-5209 or visit https://dhwsupport.dormakaba.com/hc/en-us

## NOTES:

- 1. DO NOT SCALE DRAWING.
- 2. RIGHT HAND DOOR SHOWN.
- 3. DIMENSIONS ARE IN INCHES/(MM).
- 4. CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACED COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
- 5. DPK FASTENERS FOR STEEL DOOR & FRAME ONLY.

FOR 5/16-18 MACHINE SCREWS USE #F (0.257") DRILL & TAP FOR No. 20 WOOD SCREWS USE 7/32" DRILL DPK FASTENERS DRILL 1/8" PILOT HOLE TWO (2) HOLES IN FRAME FOR ARM SHOE \_\_\_\_\_\_



