## Door Closer Models: SL6014, SL6036 TDE, TDEH Double Egress Track Installation (Pull Side Mount) with Plates BP60, BP70, BP70FC Drilling Instructions

BEST ()

For online instructions, assistance or warranty information: Call 1-800-392-5209 or visit https://dhwsupport.dormakaba.com/hc/en-us

## NOTES:

- 1. DO NOT SCALE DRAWING.
- 2. DIMENSIONS ARE IN INCHES/(MM).
- 3. RIGHT HAND DOOR SHOWN.
- 4. CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACED COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
- 5. TEMPLATE FOR 4-1/2" WIDE HINGE OR 3/4" OFFSET PIVOTS.

- 6. MINIMUM DOOR WIDTH 30"
- 7. WHEN OPENING DOOR TO 90° A MINIMUM OF 4-1/2" OF CLEARNCE IS REQUIRED BETWEEN DOOR FACE AND WALL.
- 9. HOLD OPEN RANGE 30° 110°.
- 10. DPK FASTENERS FOR STEEL DOOR & FRAME ONLY.

