

**Door Closer Models: SL6014, SL6036 IS, ISH (Integra Stop Arm)
Regular Installation (Pull Side Mount)
Drilling Instructions**

For online instructions, assistance or warranty information:
Call 1-800-392-5209 or visit <https://dhwsupport.dormakaba.com/hc/en-us>

NOTES:

1. DO NOT SCALE DRAWING.
2. DIMENSIONS ARE IN INCHES/(MM).
3. RIGHT HAND DOOR SHOWN.
4. CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACED COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
5. DPK FASTENERS FOR STEEL DOOR & FRAME ONLY.

DEGREE OF DEAD STOP	DIM. "A" CLOSER	DIM. "B" ARM SHOE
85°	8-1/8" (206)	13-7/8" (352)
90°	7-1/2" (191)	13-1/2" (343)
95°	6-11/16" (170)	13-1/4" (337)
100°	6-5/8" (168)	12-5/8" (321)
105°	6-1/8" (156)	12-1/4" (311)
110°	5-3/4" (146)	11-7/8" (302)

