

**Door Closer Models: SL6014, SL6036 FHJ
Top Jamb Installation (Push Side Mount)
Drilling Instructions**

For online instructions, assistance or warranty information:
Call 1-800-392-5209 or visit <https://dhwsupport.dormakaba.com/hc/en-us>

NOTES:

1. DO NOT SCALE DRAWING.
2. DIMENSIONS ARE IN INCHES/(MM).
3. LEFT HAND DOOR SHOWN.
4. CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACED COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
5. MAX. OPENING IS 180°.
6. SEE CATALOG FOR REVEAL INFORMATION.
7. DPK FASTENERS FOR STEEL DOOR & FRAME ONLY.

ANGLE OF OPENING	DIM. "A" CLOSER	DIM."B" ARM SHOE
TO 100°	$\frac{8"}{(203)}$	$13\text{-}1\frac{1}{2}"$ (343)
100° TO 120°	$\frac{6\text{-}1\frac{1}{2}"(165)}$	$\frac{12"}{(305)}$
OVER 120°	$\frac{4"}{(102)}$	$9\text{-}1\frac{1}{2}"$ (241)

