

**Door Closer Models: HD7016 TDE, TDEH  
Double Egress Track Installation (Pull Side Mount)  
Drilling Instructions**

For online instructions, assistance or warranty information:  
Call 1-800-392-5209 or visit <https://dhwsupport.dormakaba.com/hc/en-us>

**NOTES:**

1. DO NOT SCALE DRAWING.
2. DIMENSIONS ARE IN INCHES/(MM).
3. RIGHT HAND DOOR SHOWN.
4. CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACED COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
5. TEMPLATE FOR 4-1/2" WIDE HING OR 3/4" OFFSET PIVOTS.
6. MINIMUM DOOR WIDTH 30"
7. WHEN OPENING DOOR TO 90° A MINIMUM OF 4-1/2" OF CLEARANCE IS REQUIRED BETWEEN DOOR FACE AND WALL.
8. HOLD OPEN RANGE 30° - 110°
9. DPK FASTENERS FOR STEEL DOOR & FRAME ONLY.

