Door Closer Models: HD7016 SISJH (Spring Integra Cushion Arm) Top Jamb Installation (Push Side Mount) with Drop Plate DP70 Drilling Instructions



For online instructions, assistance or warranty information: Call 1-800-392-5209 or visit https://dhwsupport.dormakaba.com/hc/en-us

NOTES:

- 1) DO NOT SCALE THIS DRAWING
- 2) DIMENSIONS ARE IN INCHES / [MM]
- 3) LEFT HAND DOOR IS SHOWN
- 4) CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACE COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
- 5) DPK FASTENERS FOR STEEL DOOR & FRAME ONLY.
- 6) SEE CATALOG FOR REVEAL INFORMATION

ANGLE OF HOLD OPEN	ANGLE OF CUSHION	DIMENSION "A" (DROP PLATE)	DIMENSION "B" (ARM SHOE)
85°	86° - 96°	<u>7-7/8"</u> [200]	<u>9-7/8"</u> [251]
90°	91° - 101°	<u>7-3/8"</u> [187]	<u>9-3/8"</u> [238]
100°	101° - 111°	<u>6-1/2"</u> [165]	<u>8-1/2"</u> [216]

-FOR 1/4-20 MACHINE SCREWS, USE 13/64" OR #7 DRILL & TAP FOR No.14 WOOD SCREWS, USE 5/32" DRILL FOR DPK FASTENERS, USE 1/8" DRILL FOUR (4) HOLES IN FRAME ARE FOR DROP PLATE (SHOWN)

