Door Closer Models: EHD9016 PHJ Top Jamb Installation [Push Side Mount] With AB90 Angle Bracket Drilling Instructions



For online instructions, assistance or warranty information: Call 1-800-392-5209 or visit https://dhwsupport.dormakaba.com/hc/en-us

NOTES:

- 1) DRAWING IS NOT TO SCALE.
- 2) DIMENSIONS ARE IN INCHES / [MM].
- 3) RIGHT HAND DOOR IS SHOWN.
- 4) 160° MAX OPENING IS SHOWN.
- 5) CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACE COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
- 6) SEE CATALOG FOR HOLD OPEN RANGE INFORMATION.
- 7) DPK FASTENERS FOR STEEL DOOR & FRAME ONLY. 9-3/16' $3'' = 160^{\circ}$ [234] [76] 3D INTERPRETATION 6-3/16' 1-1/2" [157] [38] 5/8" [16] 9/16" [14] DOOR EDGE OF FRAME STOP FOR #12-24 MACHINE SCREWS, USE 11/64" OR #16 DRILL & TAP **BOTTOM SURFACE OF FRAME STOP** FOR No. 12 WOOD SCREWS, USE 9/64" DRILL DPK FASTENERS DRILL 1/8" PILOT HOLE FOUR (4) HOLES IN FRAME FOR PLATE 4-13/16" FOR 1/4-20 MACHINE SCREWS, USE 13/64" OR #7 DRILL & TAP [122] LEFT HAND DOOR ORIENTATION: FOR No. 14 WOOD SCREWS USE 5/32" DRILL **CENTER OF HINGE** DPK FASTENERS DRILL 1/8" PILOT HOLE FOR SEX NUTS USE 3/8" DRILL TWO (2) HOLES IN DOOR FOR ARM SHOE **6**—6 10-7/8" = 160° [276] Not to scale. Measurements are for reference only.

Not a drilling template.