


# Door Closer Models: EHD9016 PTH Parallel Track Installation [Push Side Mount] With Backplate BP90 Drilling Instructions

For online instructions, assistance or warranty information:  
Call 1-800-392-5209 or visit <https://dhwsupport.dormakaba.com/hc/en-us>


**NOTES:**

- 1) DRAWING IS NOT TO SCALE.
- 2) DIMENSIONS ARE IN INCHES / [MM].
- 3) RIGHT HAND DOOR IS SHOWN.
- 4) MOUNTING FOR 90° HOLD OPEN SHOWN.
- 5) MAXIMUM OPENING 106°, WITHOUT RUBBER STOP.
- 6) MAXIMUM OPENING 100° WITH RUBBER STOP.
- 7) CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACE COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
- 8) SEE CATALOG FOR HOLD OPEN RANGE INFORMATION.
- 9) DPK FASTENERS FOR STEEL DOOR & FRAME ONLY.

FOR 1/4-20 MACHINE SCREWS, USE 13/64" OR #7 DRILL & TAP  
FOR No. 14 WOOD SCREWS, USE 5/32" DRILL  
DPK FASTENERS DRILL 1/8" PILOT HOLE  
TWO (2) HOLES IN SOFFIT FOR TRACK



**LEFT HAND DOOR ORIENTATION:**



Not to scale. Measurements are for reference only.  
Not a drilling template.