



Mounting holes 'A'

Wood door Drill 3/32" dia pilot hole – inside

Metal door #10-24 MS or #10 SMS – inside

Sex bolts Drill 1/4" dia hole thru door
Redrill 5/16" dia hole – outside

Vertical centerline

Fold here for strike
No 020-64 (square bolt)

Fold here for strike
No 020-65 (Pullman latch)

TOT-4A Bottom H-Latch Template

For devices: 2200, FL-2200, 200, and FL-200 Series

STANLEY

DRWG T05138-11-000 DATE 8/29/07 PN 2262036 REV B PRNT SPEC ER7991-43

phi

Precision Hardware
a Division of Stanley Security Solutions, Inc.
www.stanleysecuritysolutions.com