





Scan for product details and downloads.
 Call 1-800-392-5209 or visit
<https://dhwsupport.dormakaba.com/hc/en-us>
 for assistance or warranty information.


CAUTION: * For trim outside only functions (such as 079) and trim inside only functions (such as 025 and 069), prepare surface mount trim holes on trim side of door as needed.
 † For 1DT, drill 7/64" [11] holes halfway into door at centerpoints indicated.
 †† Because these holes pass through mortise pocket, it is recommended that each hole be drilled separately rather than straight through.




9 Chisel mortise area




10 Slide mortise into pocket




11 Mark mortise holes



12 Remove mortise & Drill mortise lock holes




13 Drill lever holes




13.1 Drill lever holes selected from model chart based on your function.

14 Drill TCM hole

NOTE: If installing an electrified mortise lock, step 14 is required.




15 Mark centerline




15.1 Continue lockset centerline (located on template) onto door frame.

16 Mark center of strike




16.1 Locate and mark center of strike by measuring 1/2" [13] thickness of door.

17 Place strike template & mark holes




17.1 Place strike template centerline on lever centerline made on previous step. Center punch edges of strike and box O.


18 Connect previous strike marks




19 Drill strike hole



20 Chisel mortise area



21 Place strike & mark holes



22 Remove strike & drill strike holes

