
## NOTES:

- 1. DO NOT SCALE DRAWING.
- 2. RIGHT HAND DOOR SHOWN.
- 3. DIMENSIONS ARE IN INCHES/(MM).
- 4. CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACED COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
- 5. MAXIMUM OPENING 180°. (ALLOW CLEARANCE FOR CLOSER COVER)
- 6. SEE CATALOG FOR HOLD OPEN RANGE INFORMATION.
- 7. OPTIONAL DPK FASTENERS (DPK89) FOR STEEL DOOR & FRAME ONLY.

ANGLE OF OPENING	DIM. "A" CLOSER	DIM. "B" ARM SHOE
TO 100°	<u>11</u> (279)	12 (305)
OVER 100°	9 (229)	9-1/4 (235)




DOOR CLOSER MODELS: 8916, 8956 FH REGULAR INSTALLATION (PULL SIDE MOUNT)



DORMA Architectural Hardware Reamstown, PA 17567 NOTES:

- 1. DO NOT SCALE DRAWING.
- 2. RIGHT HAND DOOR SHOWN.
- 3. DIMENSIONS ARE IN INCHES/(MM).
  4. CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACED COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
- 5. MAXIMUM OPENING 180°. (ALLOW CLEARANCE FOR CLOSER COVER)
- 6. SEE CATALOG FOR HOLD OPEN RANGE INFORMATION.
- 7. OPTIONAL DPK FASTENERS (DPK89) FOR STEEL DOOR & FRAME ONLY.

ANGLE	DIM. "C"	DIM. "B"
OF	PLATE	ARM SHOE
OPENING		
TO 100°	9-1/4	_12_
	(235)	(305)
OVER 100°	7-1/4	9-1/4
	(184)	(235)



DOOR CLOSER MODELS: 8916, 8956 FH REGULAR INSTALLATION (PULL SIDE MOUNT) WITH PLATE BP89



**DORMA Architectural Hardware** Reamstown, PA 17567