

**Door Closer Models: HD7016 SPA, SPAT, x FTHD
Super Parallel Arm Flush Transom (Push Side Mount)
with Plates DP70, DP70FC
Template/Drilling Instructions**

Always consult BEST's website for the latest template at
<https://dhwsupport.dormakaba.com/hc/en-us> or call 1-800-392-5209.

NOTES:

1. DO NOT SCALE DRAWING.
2. DIMENSIONS ARE IN INCHES/(MM).
3. LEFT HAND DOOR SHOWN.
4. CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACED COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
5. MINIMUM DOOR WIDTH 26"
6. TEMPLATING BASED ON 4-1/2" x 2-1/2" BUTT HINGES.
7. DPK FASTENERS FOR STEEL DOOR & FRAME ONLY.

ANGLE OF OPENING HOLD OPEN	DIM. "C" PLATE	DIM. "B" FTHD BRACKET
TO 100° H.O. 90°	<u>9-3/8</u> (238)	<u>10-1/8</u> (257)
TO 180° H.O. 123°	<u>5-3/4</u> (146)	<u>6-1/2</u> (165)

