## Door Closer Models: HD7016 FH x PFT Parallel Arm Flush Transom (Push Side Mount) Template/Drilling Instructions

Always consult BEST's website for the latest template at https://dhwsupport.dormakaba.com/hc/en-us or call 1-800-392-5209.

## NOTES:

- 1. DO NOT SCALE DRAWING.
- 2. DIMENSIONS ARE IN INCHES/(MM).
- 3. LEFT HAND DOOR SHOWN.
- 4. CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACED COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
- 5. MAX. OPENING IS 180°.
- 6. DPK FASTENERS FOR STEEL DOOR & FRAME ONLY.

ANGLE OF OPENING	DIM. "A" CLOSER	DIM. "B" TRANSOM BRACKET	HOLD OPEN RANGE
TO 100°	<u>4-1/8</u> (105)	<u>9-1/4</u> (235)	60°-105°
OVER 100°	<u>1-5/8</u> (41)	$\frac{6-3/4}{(171)}$	70°-170°



