

QED Fire Latch Template

QED Feu Verrou Évalué

QED Fuego Pestillo Evaluado



Tools Needed
Herramientas necesarias
Outils nécessaires

1 Install plug.
Installez tampon.
Instale el tapón.

2 Install latch.
Installez pestillo.
Instale verrou.

#6 x 3/4"
Type AB flat head
Tipo AB cabeza plana
Type AB tête plate

