




**Full Mortise Butt Hinge (Size 4-1/2" x 4-1/2") Drilling Instructions/Template**  
**Standard Weight - CECB 179-12C & 191-12C**  
**Heavy Weight - CECB 168-12C & 199-12C**

**Tools Needed**

Herramientas necesarias  
 Outils nécessaires



 Wood Door  
 7/8" (22.2 mm)  
 Drill Bit

 Wood Door  
 7/32" (5.6 mm)  
 Drill Bit

 Metal Door  
 #12-24

