

Installation Specifications for 93KQ Cylindrical Locks with Large Strike



dormakaba Group

Template Number: Q02
Series: 93KQ
Backset: 2 3/4", 3 3/4", 5"
Trim Style: DV, MS, PH, PM
Door Thickness: 1-3/4" - 2-1/4"
***Template not to scale**

Notes

- 1 Also see the Q05 Template—Installation Template for 93KQ Cylindrical Locks.
- 2 Allow plus tolerance for clearance per ANSI A115.5. The general tolerance is $\pm 1/64"$.
- 3 The lock and latch case support are required from the door manufacturer.
- 4 The plaster guard is required from the frame manufacturer.
- 5 Prepare for a #8-32 screw.
- 6 Prepare for a #12-24 screw.
- 7 When a strike box is used, $9/64"$.
- 8 For backsets other than 2 3/4", position the vertical centerline of the lock appropriately.
- 9 Drill the 1" hole 1 3/4" deep.
- 10 Drill the 1" hole 1" deep.

