

Installation Specifications for Door and Frame Preparation for 63K, 83K, 73KC and 93K Cylindrical Locks with Large Strike (S3)

Template Number: K09
Series: 63K, 83K, 73KC, 93K
Backset: 2-3/4" [70]
Strike: Large ANSI Strike (S3)
Door Thickness: 1-3/4" [44]



For online instructions, assistance or warranty information:
 Call 1-800-392-5209 or visit <https://dhwsupport.dormakaba.com/hc/en-us>

NOTES

- 1 Allow plus tolerance for clearance per ANSI A115.2.
- 2 Lock and latch case support by door manufacturer.
- 3 Plaster guard by door manufacturer.
- 4 Prepare for a #8-32 screw.
- 5 Prepare for a #12-24 screw.
- 6 **For 73KC and 93K ONLY!** The 63K and 83K "C" style trim will **NOT** cover these holes.
- 7 For 63K and 73KC only, a 1" [25.4] latch face is available.
- 8 When a strike box is used, 9/64" [3.6].
- 9 For 73KC locks, use the KD303 drill jig to ensure that through-bolts and levers are properly aligned.

