

Series: 2300, FL2300, 300, FL300 – Strike Number: S984, S985 – Door Preparation

For online instructions, assistance or warranty information:
Call 1-800-392-5209 or visit <https://dhwsupport.dormakaba.com/hc/en-us>

Reinforcement requirements

Provide adequate reinforcement to metal-covered composite and hollow metal doors for drilling and tapping for machine screws.

NOTE: For lock stile machining see appropriate hollow metal template.

