



NOTES:

1. PREPARE FOR A #8-32 MACHINE SCREW OR FOR A #8 WOOD SCREW. (COMBINATION SCREW SUPPLIED).
2. ALLOW PLUS TOLERANCE FOR CLEARANCE PER ANSI A115.2.

NOT TO SCALE. MEASUREMENTS ARE FOR REFERENCE ONLY. NOT A DRILLING TEMPLATE.

TMP NO.
91829

PAGE 1 OF 1

REV. 08/22

2101 STRIKE
METAL OR WOOD JAMB

dormakaba 

dormakaba USA Inc.