

DAP-3 Installation Instructions

Prepare door and frame to template T90-31. The hardware can be adjusted for $\frac{3}{4}$ " to 1" undercuts by adding or removing supplied washers. Set door on stud of bottom jamb bracket. Lower previously retracted stud in the header plate.



STANLEY

Hardware

