


Mark and drill holes

- 1 Determine the inside and outside of the door, then mark and drill each side of the door according to proper function. See *H03 or H14 Installation Specifications* and *H04 Hole Pattern Chart*.
- 2 For best results, cut the template along the dotted lines and align the arrows with the marked centerlines.
- 3 Use the other side of this template for marking the other side of the door.
- 4 Mark the horizontal centerline of the strike $3/8$ " above the horizontal centerline of the lock. See the *Installation Instructions* and the *H03 or H14 Installation Specifications*.

- 1 **Cylinder hole**
1 1/4" dia. Drill only if the cylinder hole is required on this side of the door. See *H04 Hole Pattern Chart*.
- 2 **Turn knob or emergency entrance hole**
1/2" dia. Drill only if the turn knob or emergency entrance hole is required on this side of the door. See *H04 Hole Pattern Chart*.
- 3 **Hotel indicator hole**
1/2" dia. Drill only if the hotel indicator hole is required on this side of the door. See *H04 Hole Pattern Chart*.
- 4 **Knob hole**
7/8" dia. Drill only if the knob hole is required on this side of the door. See *H04 Hole Pattern Chart*.
- 5 **Through-bolt hole**
3/8" dia x 2 holes. Drill through the door. See *H04 Hole Pattern Chart*.
- 6 **Forged trim hole**
5/8" dia x 2 holes. Drill only for 'M' or 'N' forged full-plate escutcheons. See *H04 Hole Pattern Chart*.



Title

Installation Template for 34H-37H Mortise Locks

BEST ACCESS SYSTEMS

Series

34H-37H

Backset

2 3/4"

Trim style

M & N

Door thickness

1 3/4"-5"

Rev date


10/2003

Template number

H13

Rev

H



Mark and drill holes

- 1 Determine the inside and outside of the door, then mark and drill each side of the door according to proper function. See *H03 or H14 Installation Specifications* and *H04 Hole Pattern Chart*.
- 2 For best results, cut the template along the dotted lines and align the arrows with the marked centerlines.
- 3 Use the other side of this template for marking the other side of the door.
- 4 Mark the horizontal centerline of the strike 3/8" above the horizontal centerline of the lock. See the *Installation Instructions* and the *H03 or H14 Installation Specifications*.

① Cylinder hole
 1 1/4" dia. Drill only if the cylinder hole is required on this side of the door. See *H04 Hole Pattern Chart*.

② Turn knob or emergency entrance hole
 1/2" dia. Drill only if the turn knob or emergency entrance hole is required on this side of the door. See *H04 Hole Pattern Chart*.

③ Hotel indicator hole
 1/2" dia. Drill only if the hotel indicator hole is required on this side of the door. See *H04 Hole Pattern Chart*.

④ Knob hole
 7/8" dia. Drill only if the knob hole is required on this side of the door. See *H04 Hole Pattern Chart*.

⑤ Through-bolt hole
 3/8" dia x 2 holes. Drill through the door. See *H04 Hole Pattern Chart*.

⑥ Forged trim hole
 5/8" dia x 2 holes. Drill only for 'M' or 'N' forged full-plate escutcheons. See *H04 Hole Pattern Chart*.

Note

- 1 This template is for wood doors only.

