

MULLION STABILIZER FOR FL-KR-822 APPLICATION

Mark centers per dimensions below, then drill and tap for 4- 1/4-20 M.S.
Attach one stabilizer to each door leaf.

