

Maintenance of CB 5 knuckle concealed bearing line of hinges

As required apply Shell Darina # 2, or equivalent grease at the non load bearing center hinge knuckle and pin*. Bearings do not have to be lubricated as they contain polytetrafluoroethylene.

Hinge surface should be kept clean. Use a soft damp cloth free of any chemicals that would harm the protective lacquer coating.

* To lubricate hinges, extract pins and wipe or dip with grease. Reinsert pin. Grease will work into load bearing surfaces. Wipe excess grease and dirt from hinge.



STANLEY

Hardware

