


# PARTS LIST 9500/F9500 SERIES MORTISE EXIT DEVICE



9500/F9500 SERVICE PARTS LIST (Rev 02-16)

ITEM #	Item #	Part #	DESCRIPTION
1	CHASASSY95LHR	95057524	CHASSIS ASSEMBLY 9500 EXIT DEVICE LH (Includes Lifter Arm)
1B	CHASASSY95RHR	95057525	CHASSIS ASSEMBLY 9500 EXIT DEVICE RH (Incudes Lifter Arm)
2	CHCOV91/95 689	18002353	CHASSIS COVER 9100 / 9500 689
2	CHCOV91/95 691	18002356	CHASSIS COVER 9100 / 9500 691
2	CHCOV91/95 693	CHCOV91/95 693	CHASSIS COVER 9100 / 9500 693
2	CHCOV91/95 695	18002354	CHASSIS COVER 9100 / 9500 695
2	CHCOV91/95 696	18002355	CHASSIS COVER 9100 / 9500 696
2	CHCOV91/95 605	18002363	CHASSIS COVER 9100 / 9500 605
2	CHCOV91/95 606	18002358	CHASSIS COVER 9100 / 9500 606
2	CHCOV91/95 611	18002364	CHASSIS COVER 9100 / 9500 611
2	CHCOV91/95 612	18002359	CHASSIS COVER 9100 / 9500 612
2	CHCOV91/95 613	18002362	CHASSIS COVER 9100 / 9500 613
2	CHCOV91/95 619	95056714	CHASSIS COVER 9100 / 9500 619 (630P)
2	CHCOV91/95 625	18002365	CHASSIS COVER 9100 / 9500 625
2	CHCOV91/95 626	18002361	CHASSIS COVER 9100 / 9500 626
2	CHCOV91/95 630	18002360	CHASSIS COVER 9100 / 9500 630
3	TBRA689	18002220	TBAR ASSY, 9000 A 689
3	TBRA695	18002221	TBAR ASSY, 9000 A 695
3	TBRA696	18002222	TBAR ASSY, 9000 A 696
3	TBRA691	18002223	TBAR ASSY, 9000 A 691
3	TBRA693	18003010	TBAR ASSY, 9000 A 693
3	TBRA605	18002230	TBAR ASSY, 9000 A 605
3	TBRA606	18002225	TBAR ASSY, 9000 A 606
3	TBRA611	18002231	TBAR ASSY, 9000 A 611
3	TBRA612	18002226	TBAR ASSY, 9000 A 612
3	TBRA613	18002229	TBAR ASSY, 9000 A 613
3	TBRA619	TBRA619	TBAR ASSY, 9000 A 619
3	TBRA625	18002232	TBAR ASSY, 9000 A 625
3	TBRA626	18002228	TBAR ASSY, 9000 A 626
3	TBRA630	18002227	TBAR ASSY, 9000 A 630
3	TBRB689	18002233	TBAR ASSY, 9000 B 689
3	TBRB695	18002234	TBAR ASSY, 9000 B 695
3	TBRB696	18002235	TBAR ASSY, 9000 B 696
3	TBRB691	18002236	TBAR ASSY, 9000 B 691
3	TBRB693	TBRB693	TBAR ASSY, 9000 B 693
3	TBRB605	18002243	TBAR ASSY, 9000 B 605
3	TBRB606	18002238	TBAR ASSY, 9000 B 606
3	TBRB611	18002244	TBAR ASSY, 9000 B 611
3	TBRB612	18002239	TBAR ASSY, 9000 B 612
3	TBRB613	18002242	TBAR ASSY, 9000 B 613
3	TBRB619	TBRB619	TBAR ASSY, 9000 B 619
3	TBRB625	18002245	TBAR ASSY, 9000 B 625
3	TBRB626	18002241	TBAR ASSY, 9000 B 626
3	TBRB630	18002240	TBAR ASSY, 9000 B 630
3A	FTBRA689	18002246	TBAR ASSY, F9000 A 689
3A	FTBRA695	18002247	TBAR ASSY, F9000 A 695
3A	FTBRA696	18002248	TBAR ASSY, F9000 A 696
3A	FTBRA691	18002249	TBAR ASSY, F9000 A 691
3A	FTBRA693	FTBRA693	TBAR ASSY, F9000 A 693
3A	FTBRA605	18002256	TBAR ASSY, F9000 A 605
3A	FTBRA606	18002251	TBAR ASSY, F9000 A 606
3A	FTBRA611	18002257	TBAR ASSY, F9000 A 611
3A	FTBRA612	18002252	TBAR ASSY, F9000 A 612
3A	FTBRA613	18002255	TBAR ASSY, F9000 A 613
3A	FTBRA619	FTBRA619	TBAR ASSY, F9000 A 619
3A	FTBRA625	18002258	TBAR ASSY, F9000 A 625
3A	FTBRA626	18002254	TBAR ASSY, F9000 A 626
3A	FTBRA630	18002253	TBAR ASSY, F9000 A 630
3A	FTBRB689	18002259	TBAR ASSY, F9000 B 689
3A	FTBRB695	18002260	TBAR ASSY, F9000 B 695

9500/F9500 SERVICE PARTS LIST (Rev 02-16)

ITEM #	Item #	Part #	DESCRIPTION
3A	FTBRB696	18002261	TBAR ASSY, F9000 B 696
3A	FTBRB691	18002262	TBAR ASSY, F9000 B 691
3A	FTBRB693	FTBRB693	TBAR ASSY, F9000 B 693
3A	FTBRB605	18002269	TBAR ASSY, F9000 B 605
3A	FTBRB606	18002264	TBAR ASSY, F9000 B 606
3A	FTBRB611	18002270	TBAR ASSY, F9000 B 611
3A	FTBRB612	18002265	TBAR ASSY, F9000 B 612
3A	FTBRB613	18002268	TBAR ASSY, F9000 B 613
3A	FTBRB619	FTBRB619	TBAR ASSY, F9000 B 619
3A	FTBRB625	18002271	TBAR ASSY, F9000 B 625
3A	FTBRB626	18002267	TBAR ASSY, F9000 B 626
3A	FTBRB630	18002266	TBAR ASSY, F9000 B 630
3B	MLR TBR A 689	MLR TBR A 689	MLR TOUCHBAR RAIL ASSY. 9000 A 689 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR A 695	MLR TBR A 695	MLR TOUCHBAR RAIL ASSY. 9000 A 695 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR A 696	MLR TBR A 696	MLR TOUCHBAR RAIL ASSY. 9000 A 696 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR A 691	MLR TBR A 691	MLR TOUCHBAR RAIL ASSY. 9000 A 691 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR A 693	MLR TBR A 693	MLR TOUCHBAR RAIL ASSY. 9000 A 693 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR A 605	MLR TBR A 605	MLR TOUCHBAR RAIL ASSY. 9000 A 605 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR A 606	MLR TBR A 606	MLR TOUCHBAR RAIL ASSY. 9000 A 606 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR A 611	MLR TBR A 611	MLR TOUCHBAR RAIL ASSY. 9000 A 611 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR A 612	MLR TBR A 612	MLR TOUCHBAR RAIL ASSY. 9000 A 612 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR A 613	MLR TBR A 613	MLR TOUCHBAR RAIL ASSY. 9000 A 613 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR A 619	MLR TBR A 619	MLR TOUCHBAR RAIL ASSY. 9000 A 619 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR A 625	MLR TBR A 625	MLR TOUCHBAR RAIL ASSY. 9000 A 625 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR A 626	MLR TBR A 626	MLR TOUCHBAR RAIL ASSY. 9000 A 626 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR A 630	MLR TBR A 630	MLR TOUCHBAR RAIL ASSY. 9000 A 630 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR B 689	MLR TBR B 689	MLR TOUCHBAR RAIL ASSY. 9000 B 689 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR B 695	MLR TBR B 695	MLR TOUCHBAR RAIL ASSY. 9000 B 695 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR B 696	MLR TBR B 696	MLR TOUCHBAR RAIL ASSY. 9000 B 696 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR B 691	MLR TBR B 691	MLR TOUCHBAR RAIL ASSY. 9000 B 691 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR B 693	MLR TBR B 693	MLR TOUCHBAR RAIL ASSY. 9000 B 693 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR B 605	MLR TBR B 605	MLR TOUCHBAR RAIL ASSY. 9000 B 605 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR B 606	MLR TBR B 606	MLR TOUCHBAR RAIL ASSY. 9000 B 606 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR B 611	MLR TBR B 611	MLR TOUCHBAR RAIL ASSY. 9000 B 611 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR B 612	MLR TBR B 612	MLR TOUCHBAR RAIL ASSY. 9000 B 612 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR B 613	MLR TBR B 613	MLR TOUCHBAR RAIL ASSY. 9000 B 613 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR B 619	MLR TBR B 619	MLR TOUCHBAR RAIL ASSY. 9000 B 619 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR B 625	MLR TBR B 625	MLR TOUCHBAR RAIL ASSY. 9000 B 625 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR B 626	MLR TBR B 626	MLR TOUCHBAR RAIL ASSY. 9000 B 626 (REQUIRES PS 610RF POWER SUPPLY)
3B	MLR TBR B 630	MLR TBR B 630	MLR TOUCHBAR RAIL ASSY. 9000 B 630 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR A 689	MLR FTBR A 689	MLR TOUCHBAR RAIL ASSY. F9000 A 689 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR A 695	MLR FTBR A 695	MLR TOUCHBAR RAIL ASSY. F9000 A 695 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR A 696	MLR FTBR A 696	MLR TOUCHBAR RAIL ASSY. F9000 A 696 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR A 691	MLR FTBR A 691	MLR TOUCHBAR RAIL ASSY. F9000 A 691 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR A 693	MLR FTBR A 693	MLR TOUCHBAR RAIL ASSY. F9000 A 693 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR A 605	MLR FTBR A 605	MLR TOUCHBAR RAIL ASSY. F9000 A 605 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR A 606	MLR FTBR A 606	MLR TOUCHBAR RAIL ASSY. F9000 A 606 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR A 611	MLR FTBR A 611	MLR TOUCHBAR RAIL ASSY. F9000 A 611 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR A 612	MLR FTBR A 612	MLR TOUCHBAR RAIL ASSY. F9000 A 612 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR A 613	MLR FTBR A 613	MLR TOUCHBAR RAIL ASSY. F9000 A 613 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR A 619	MLR FTBR A 619	MLR TOUCHBAR RAIL ASSY. F9000 A 619 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR A 625	MLR FTBR A 625	MLR TOUCHBAR RAIL ASSY. F9000 A 625 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR A 626	MLR FTBR A 626	MLR TOUCHBAR RAIL ASSY. F9000 A 626 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR A 630	MLR FTBR A 630	MLR TOUCHBAR RAIL ASSY. F9000 A 630 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR B 689	MLR FTBR B 689	MLR TOUCHBAR RAIL ASSY. F9000 B 689 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR B 695	MLR FTBR B 695	MLR TOUCHBAR RAIL ASSY. F9000 B 695 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR B 696	MLR FTBR B 696	MLR TOUCHBAR RAIL ASSY. F9000 B 696 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR B 691	MLR FTBR B 691	MLR TOUCHBAR RAIL ASSY. F9000 B 691 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR B 693	MLR FTBR B 693	MLR TOUCHBAR RAIL ASSY. F9000 B 693 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR B 605	MLR FTBR B 605	MLR TOUCHBAR RAIL ASSY. F9000 B 605 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR B 606	MLR FTBR B 606	MLR TOUCHBAR RAIL ASSY. F9000 B 606 (REQUIRES PS 610RF POWER SUPPLY)

9500/F9500 SERVICE PARTS LIST (Rev 02-16)

ITEM #	Item #	Part #	DESCRIPTION
3C	MLR FTBR B 611	MLR FTBR B 611	MLR TOUCHBAR RAIL ASSY. F9000 B 611 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR B 612	MLR FTBR B 612	MLR TOUCHBAR RAIL ASSY. F9000 B 612 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR B 613	MLR FTBR B 613	MLR TOUCHBAR RAIL ASSY. F9000 B 613 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR B 619	MLR FTBR B 619	MLR TOUCHBAR RAIL ASSY. F9000 B 619 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR B 625	MLR FTBR B 625	MLR TOUCHBAR RAIL ASSY. F9000 B 625 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR B 626	MLR FTBR B 626	MLR TOUCHBAR RAIL ASSY. F9000 B 626 (REQUIRES PS 610RF POWER SUPPLY)
3C	MLR FTBR B 630	MLR FTBR B 630	MLR TOUCHBAR RAIL ASSY. F9000 B 630 (REQUIRES PS 610RF POWER SUPPLY)
	PS610RF	33400018	POWER SUPPLY TO BE USED WITH MLR 9000 SERIES EXITS
4	9AHD	95059476	ENDCAP BRACKET WITH SCREW PACK 9000 (9A)
5	EC 689	18002285	ENDCAP 9000 689 (Includes Endcap Mounting Bracket & Mounting Screws)
5	EC 691	18002288	ENDCAP 9000 691 (Includes Endcap Mounting Bracket & Mounting Screws)
5	EC 693	18002296	ENDCAP 9000 693 (Includes Endcap Mounting Bracket & Mounting Screws)
5	EC 695	18002286	ENDCAP 9000 695 (Includes Endcap Mounting Bracket & Mounting Screws)
5	EC 696	18002287	ENDCAP 9000 696 (Includes Endcap Mounting Bracket & Mounting Screws)
5	EC 605	18002295	ENDCAP 9000 605 (Includes Endcap Mounting Bracket & Mounting Screws)
5	EC 606	18002290	ENDCAP 9000 606 (Includes Endcap Mounting Bracket & Mounting Screws)
5	EC 611	18002296	ENDCAP 9000 611 (Includes Endcap Mounting Bracket & Mounting Screws)
5	EC 612	18002291	ENDCAP 9000 612 (Includes Endcap Mounting Bracket & Mounting Screws)
5	EC 613	18002294	ENDCAP 9000 613 (Includes Endcap Mounting Bracket & Mounting Screws)
5	EC 619	18002388	ENDCAP 9000 619 (Includes Endcap Mounting Bracket & Mounting Screws)
5	EC 625	18002297	ENDCAP 9000 625 (Includes Endcap Mounting Bracket & Mounting Screws)
5	EC 626	18002293	ENDCAP 9000 626 (Includes Endcap Mounting Bracket & Mounting Screws)
5	EC 630	18002292	ENDCAP 9000 630 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	FEC 689	18002298	ENDCAP F9000 689 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	FEC 691	18002301	ENDCAP F9000 691 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	FEC 693	18002391	ENDCAP F9000 693 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	FEC 695	18002299	ENDCAP F9000 695 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	FEC 696	18002300	ENDCAP F9000 696 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	FEC 605	18002308	ENDCAP F9000 605 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	FEC 606	18002303	ENDCAP F9000 606 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	FEC 611	18002309	ENDCAP F9000 611 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	FEC 612	18002304	ENDCAP F9000 612 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	FEC 613	18002307	ENDCAP F9000 613 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	FEC 619	95061868	ENDCAP F9000 619 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	FEC 625	18002310	ENDCAP F9000 625 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	FEC 626	95071296	ENDCAP F9000 626 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	FEC 630	18002305	ENDCAP F9000 630 (Includes Endcap Mounting Bracket & Mounting Screws)
6	9HSCRPAK	95059919	9H SCREW PACK 9300, 695, 691, 613, 693
6	9ISCRPAK	95059536	9I SCREW PACK 9300 689, 628, 630,626,625
6	9JSCRPAK	95061024	9J SCREW PACK 9300 696, 605, 606
6	9KSCRPAK	95070386	9K SCREW PACK 9300 611, 612
7	DOGKEYPAK	95002638	DOGGING KEY PACK (10 Keys Pack)
8	465	95071418	STRIKE PACK
10	565M	95071830	STRIKE PACK OPEN BACK - NON HANDED
9	9 CHASSCRPAK	95059479	9B SCREW PACK CHASSIS MOUNTING 9100, 9300, 9400, 9500
9A	F 9CHASSCRPAK	95059917	9CSCREW PACK CHASSIS MOUNTING F 9100, F9300, F9400, F9500
11	95LFTARLHR	95059511	9500 CHASSIS LIFTER ARM LHR
11	95LFTARRHR	95059512	9500 CHASSIS LIFTER ARM RHR

9500/F9500 SERVICE PARTS LIST (Rev 02-16)

ITEM #	Item #	Part #	DESCRIPTION
15	9500MLB 689	95071498	9500 MORTISE LOCK BODY 03/05/08 KIT 689
15	9500MLB 605	95071494	9500 MORTISE LOCK BODY 03/05/08 KIT 605
15	9500MLB 606	95071495	9500 MORTISE LOCK BODY 03/05/08 KIT 606
15	9500MLB 612	95071496	9500 MORTISE LOCK BODY 03/05/08 KIT 612
15	9500MLB 613	95071497	9500 MORTISE LOCK BODY 03/05/08 KIT 613
15	9500MLB 626	95071499	9500 MORTISE LOCK BODY 03/05/08 KIT 626
15	9500MLB 630	95071498	9500 MORTISE LOCK BODY 03/05/08 KIT 630
15	F9500MLB 689	95071506	9500 MORTISE LOCK BODY 03/05/08 KIT 689 FIRE
15	F9500MLB 605	95071501	9500 MORTISE LOCK BODY 03/05/08 KIT 605 FIRE
15	F9500MLB 606	95071502	9500 MORTISE LOCK BODY 03/05/08 KIT 606 FIRE
15	F9500MLB 612	95071503	9500 MORTISE LOCK BODY 03/05/08 KIT 612 FIRE
15	F9500MLB 613	95071504	9500 MORTISE LOCK BODY 03/05/08 KIT 613 FIRE
15	F9500MLB 626	95071505	9500 MORTISE LOCK BODY 03/05/08 KIT 626 FIRE
15	F9500MLB 630	95071477	9500 MORTISE LOCK BODY 03/05/08 KIT 630 FIRE
15	9500MLB LFSF689	95071517	9500 LFSF MORTISE LOCK BODY 03/05/08 KIT 689
15	9500MLB LFSF605	95071513	9500 LFSF MORTISE LOCK BODY 03/05/08 KIT 605
15	9500MLB LFSF606	95071514	9500 LFSF MORTISE LOCK BODY 03/05/08 KIT 606
15	9500MLB LFSF612	95071515	9500 LFSF MORTISE LOCK BODY 03/05/08 KIT 612
15	9500MLB LFSF613	95071516	9500 LFSF MORTISE LOCK BODY 03/05/08 KIT 613
15	9500MLB LFSF626	95071518	9500 LFSF MORTISE LOCK BODY 03/05/08 KIT 626
15	9500MLB LFSF630	95071519	9500 LFSF MORTISE LOCK BODY 03/05/08 KIT 630
15	F9500MLB LFSF689	95071531	9500 LFSF MORTISE LOCK BODY 03/05/08 KIT 689 FIRE
15	F9500MLB LFSF605	95071527	9500 LFSF MORTISE LOCK BODY 03/05/08 KIT 605 FIRE
15	F9500MLB LFSF606	95071528	9500 LFSF MORTISE LOCK BODY 03/05/08 KIT 606 FIRE
15	F9500MLB LFSF612	95071529	9500 LFSF MORTISE LOCK BODY 03/05/08 KIT 612 FIRE
15	F9500MLB LFSF613	95071530	9500 LFSF MORTISE LOCK BODY 03/05/08 KIT 613 FIRE
15	F9500MLB LFSF626	95071532	9500 LFSF MORTISE LOCK BODY 03/05/08 KIT 626 FIRE
15	F9500MLB LFSF630	95071533	9500 LFSF MORTISE LOCK BODY 03/05/08 KIT 630 FIRE
15	9500MLB LFSC689	95071524	9500 LFSC MORTISE LOCK BODY 03/05/08 KIT 689
15	9500MLB LFSC605	95071520	9500 LFSC MORTISE LOCK BODY 03/05/08 KIT 605
15	9500MLB LFSC606	95071521	9500 LFSC MORTISE LOCK BODY 03/05/08 KIT 606
15	9500MLB LFSC612	95071522	9500 LFSC MORTISE LOCK BODY 03/05/08 KIT 612
15	9500MLB LFSC613	95071523	9500 LFSC MORTISE LOCK BODY 03/05/08 KIT 613
15	9500MLB LFSC626	95071525	9500 LFSC MORTISE LOCK BODY 03/05/08 KIT 626
15	9500MLB LFSC630	95071526	9500 LFSC MORTISE LOCK BODY 03/05/08 KIT 630
15	F9500MLB LFSC689	95071538	9500 LFSC MORTISE LOCK BODY 03/05/08 KIT 689 FIRE
15	F9500MLB LFSC605	95071534	9500 LFSC MORTISE LOCK BODY 03/05/08 KIT 605 FIRE
15	F9500MLB LFSC606	95071535	9500 LFSC MORTISE LOCK BODY 03/05/08 KIT 606 FIRE
15	F9500MLB LFSC612	95071536	9500 LFSC MORTISE LOCK BODY 03/05/08 KIT 612 FIRE
15	F9500MLB LFSC613	95071537	9500 LFSC MORTISE LOCK BODY 03/05/08 KIT 613 FIRE
15	F9500MLB LFSC626	95071539	9500 LFSC MORTISE LOCK BODY 03/05/08 KIT 626 FIRE
15	F9500MLB LFSC630	95071540	9500 LFSC MORTISE LOCK BODY 03/05/08 KIT 630 FIRE
16	95FACEPLT626-630	95071739	ARMOR FACE PLATE 19020 626/630/689
16	95FACEPLT605	19020 605	ARMOR FACE PLATE PACK 605
16	95FACEPLT606	19020 606	ARMOR FACE PLATE PACK 606
16	95FACEPLT611	19020 611	ARMOR FACE PLATE PACK 611
16	95FACEPLT612	19020 612	ARMOR FACE PLATE PACK 612
16	95FACEPLT613	19020 613	ARMOR FACE PLATE PACK 613
16	95FACEPLT625	19020 629	ARMOR FACE PLATE PACK 625
	95CRKT LHR	95055312	CHASSIS KIT 9500LHR
	95CRKT RHR	95055313	CHASSIS KIT 9500RHR
	9DRKIT	95052774	DOGGING REPAIR KIT 5000/9000
	MSKIT	95059473	MICRO SWITCH REQUEST TO EXIT KIT
	CDK KIT A 689	95070582	CYLINDER DOGGING KIT 9000 A 689
	CDK KIT A 691	95002334	CYLINDER DOGGING KIT 9000 A 691
	CDK KIT A 693	CDK KIT A 693	CYLINDER DOGGING KIT 9000 A 693
	CDK KIT A 695	95002338	CYLINDER DOGGING KIT 9000 A 695
	CDK KIT A 696	95002346	CYLINDER DOGGING KIT 9000 A 696

9500/F9500 SERVICE PARTS LIST (Rev 02-16)

ITEM #	Item #	Part #	DESCRIPTION
	CDK KIT A 605	95002352	CYLINDER DOGGING KIT 9000 A 605
	CDK KIT A 606	95002356	CYLINDER DOGGING KIT 9000 A 606
	CDK KIT A 611	95002360	CYLINDER DOGGING KIT 9000 A 611
	CDK KIT A 612	95002364	CYLINDER DOGGING KIT 9000 A 612
	CDK KIT A 613	95002368	CYLINDER DOGGING KIT 9000 A 613
	CDK KIT A 619	CDK KIT A 619	CYLINDER DOGGING KIT 9000 A 619
	CDK KIT A 625	95002372	CYLINDER DOGGING KIT 9000 A 625
	CDK KIT A 626	95002376	CYLINDER DOGGING KIT 9000 A 626
	CDK KIT A 630	95060615	CYLINDER DOGGING KIT 9000 A 630
	CDK KIT B 689	95070582	CYLINDER DOGGING KIT 9000 B 689
	CDK KIT B 691	95002336	CYLINDER DOGGING KIT 9000 B 691
	CDK KIT B 693	CDK KIT B 693	CYLINDER DOGGING KIT 9000 B 693
	CDK KIT B 695	95002340	CYLINDER DOGGING KIT 9000 B 695
	CDK KIT B 696	95002348	CYLINDER DOGGING KIT 9000 B 696
	CDK KIT B 605	95002354	CYLINDER DOGGING KIT 9000 B 605
	CDK KIT B 606	95002358	CYLINDER DOGGING KIT 9000 B 606
	CDK KIT B 611	95002362	CYLINDER DOGGING KIT 9000 B 611
	CDK KIT B 612	95002366	CYLINDER DOGGING KIT 9000 B 612
	CDK KIT B 613	95002370	CYLINDER DOGGING KIT 9000 B 613
	CDK KIT B 619	CDK KIT B 619	CYLINDER DOGGING KIT 9000 B 619
	CDK KIT B 625	95002374	CYLINDER DOGGING KIT 9000 B 625
	CDK KIT B 626	95002378	CYLINDER DOGGING KIT 9000 B 626
	CDK KIT B 630	95059951	CYLINDER DOGGING KIT 9000 B 630
	CYL NUT	95060028	CYLINDER NUT
	CYL DOG BRKT	95060488	CYLINDER DOGGING BRACKET
	BPA KIT A 689	95068960	BATTERY POWERED ALARM 9000 A 689
	BPA KIT A 691	BPA KIT A 691	BATTERY POWERED ALARM 9000 A 691
	BPA KIT A 693	95062045	BATTERY POWERED ALARM 9000 A 693
	BPA KIT A 695	BPA KIT A 695	BATTERY POWERED ALARM 9000 A 695
	BPA KIT A 696	BPA KIT A 696	BATTERY POWERED ALARM 9000 A 696
	BPA KIT A 605	BPA KIT A 605	BATTERY POWERED ALARM 9000 A 605
	BPA KIT A 606	BPA KIT A 606	BATTERY POWERED ALARM 9000 A 606
	BPA KIT A 611	BPA KIT A 611	BATTERY POWERED ALARM 9000 A 611
	BPA KIT A 612	BPA KIT A 612	BATTERY POWERED ALARM 9000 A 612
	BPA KIT A 613	BPA KIT A 613	BATTERY POWERED ALARM 9000 A 613
	BPA KIT A 619	BPA KIT A 619	BATTERY POWERED ALARM 9000 A 619
	BPA KIT A 625	BPA KIT A 625	BATTERY POWERED ALARM 9000 A 625
	BPA KIT A 626	95062077	BATTERY POWERED ALARM 9000 A 626
	BPA KIT A 630	95060830	BATTERY POWERED ALARM 9000 A 630
	BPA KIT B 689	95068961	BATTERY POWERED ALARM 9000 B 689
	BPA KIT B 691	BPA KIT B 691	BATTERY POWERED ALARM 9000 B 691
	BPA KIT B 693	95062046	BATTERY POWERED ALARM 9000 B 693
	BPA KIT B 695	95061151	BATTERY POWERED ALARM 9000 B 695
	BPA KIT B 696	BPA KIT B 696	BATTERY POWERED ALARM 9000 B 696
	BPA KIT B 605	BPA KIT B 605	BATTERY POWERED ALARM 9000 B 605
	BPA KIT B 606	95071306	BATTERY POWERED ALARM 9000 B 606
	BPA KIT B 611	BPA KIT B 611	BATTERY POWERED ALARM 9000 B 611
	BPA KIT B 612	95061221	BATTERY POWERED ALARM 9000 B 612
	BPA KIT B 613	95060378	BATTERY POWERED ALARM 9000 B 613
	BPA KIT B 619	BPA KIT B 619	BATTERY POWERED ALARM 9000 B 619
	BPA KIT B 625	BPA KIT B 625	BATTERY POWERED ALARM 9000 B 625
	BPA KIT B 626	95061915	BATTERY POWERED ALARM 9000 B 626
	BPA KIT B 630	95059486	BATTERY POWERED ALARM 9000 B 630
	BPAR KIT A 689	BPAR KIT A 689	BATTERY POWERED ALARM 9000 AUTO REARM A 689
	BPAR KIT A 691	BPAR KIT A 691	BATTERY POWERED ALARM 9000 AUTO REARM A 691
	BPAR KIT A 693	BPAR KIT A 693	BATTERY POWERED ALARM 9000 AUTO REARM A 693
	BPAR KIT A 695	BPAR KIT A 695	BATTERY POWERED ALARM 9000 AUTO REARM A 695
	BPAR KIT A 696	BPAR KIT A 696	BATTERY POWERED ALARM 9000 AUTO REARM A 696
	BPAR KIT A 605	BPAR KIT A 605	BATTERY POWERED ALARM 9000 AUTO REARM A 605

9500/F9500 SERVICE PARTS LIST (Rev 02-16)

ITEM #	Item #	Part #	DESCRIPTION
	BPAR KIT A 606	BPAR KIT A 606	BATTERY POWERED ALARM 9000 AUTO REARM A 606
	BPAR KIT A 611	BPAR KIT A 611	BATTERY POWERED ALARM 9000 AUTO REARM A 611
	BPAR KIT A 612	BPAR KIT A 612	BATTERY POWERED ALARM 9000 AUTO REARM A 612
	BPAR KIT A 613	BPAR KIT A 613	BATTERY POWERED ALARM 9000 AUTO REARM A 613
	BPAR KIT A 619	BPAR KIT A 619	BATTERY POWERED ALARM 9000 AUTO REARM A 619
	BPAR KIT A 625	BPAR KIT A 625	BATTERY POWERED ALARM 9000 AUTO REARM A 625
	BPAR KIT A 626	BPAR KIT A 626	BATTERY POWERED ALARM 9000 AUTO REARM A 626
	BPAR KIT A 630	BPAR KIT A 630	BATTERY POWERED ALARM 9000 AUTO REARM A 630
	BPAR KIT B 689	95060570	BATTERY POWERED ALARM 9000 AUTO REARM B 689
	BPAR KIT B 691	BPAR KIT B 691	BATTERY POWERED ALARM 9000 AUTO REARM B 691
	BPAR KIT B 693	BPAR KIT B 693	BATTERY POWERED ALARM 9000 AUTO REARM B 693
	BPAR KIT B 695	BPAR KIT B 695	BATTERY POWERED ALARM 9000 AUTO REARM B 695
	BPAR KIT B 696	BPAR KIT B 696	BATTERY POWERED ALARM 9000 AUTO REARM B 696
	BPAR KIT B 605	95071105	BATTERY POWERED ALARM 9000 AUTO REARM B 605
	BPAR KIT B 606	BPAR KIT B 606	BATTERY POWERED ALARM 9000 AUTO REARM B 606
	BPAR KIT B 611	BPAR KIT B 611	BATTERY POWERED ALARM 9000 AUTO REARM B 611
	BPAR KIT B 612	BPAR KIT B 612	BATTERY POWERED ALARM 9000 AUTO REARM B 612
	BPAR KIT B 613	BPAR KIT B 613	BATTERY POWERED ALARM 9000 AUTO REARM B 613
	BPAR KIT B 619	BPAR KIT B 619	BATTERY POWERED ALARM 9000 AUTO REARM B 619
	BPAR KIT B 625	BPAR KIT B 625	BATTERY POWERED ALARM 9000 AUTO REARM B 625
	BPAR KIT B 626	95071287	BATTERY POWERED ALARM 9000 AUTO REARM B 626
	BPAR KIT B 630	95060500	BATTERY POWERED ALARM 9000 AUTO REARM B 630
	DWA KIT A 689	DWA KIT A 689	DIRECT WIRED ALARM 9000 A 689
	DWA KIT A 691	DWA KIT A 691	DIRECT WIRED ALARM 9000 A 691
	DWA KIT A 693	DWA KIT A 693	DIRECT WIRED ALARM 9000 A 693
	DWA KIT A 695	DWA KIT A 695	DIRECT WIRED ALARM 9000 A 695
	DWA KIT A 696	DWA KIT A 696	DIRECT WIRED ALARM 9000 A 696
	DWA KIT A 605	DWA KIT A 605	DIRECT WIRED ALARM 9000 A 605
	DWA KIT A 606	DWA KIT A 606	DIRECT WIRED ALARM 9000 A 606
	DWA KIT A 611	DWA KIT A 611	DIRECT WIRED ALARM 9000 A 611
	DWA KIT A 612	DWA KIT A 612	DIRECT WIRED ALARM 9000 A 612
	DWA KIT A 613	DWA KIT A 613	DIRECT WIRED ALARM 9000 A 613
	DWA KIT A 619	DWA KIT A 619	DIRECT WIRED ALARM 9000 A 619
	DWA KIT A 625	DWA KIT A 625	DIRECT WIRED ALARM 9000 A 625
	DWA KIT A 626	DWA KIT A 626	DIRECT WIRED ALARM 9000 A 626
	DWA KIT A 630	95070025	DIRECT WIRED ALARM 9000 A 630
	DWA KIT B 689	95071005	DIRECT WIRED ALARM 9000 B 689
	DWA KIT B 691	DWA KIT B 691	DIRECT WIRED ALARM 9000 B 691
	DWA KIT B 693	DWA KIT B 693	DIRECT WIRED ALARM 9000 B 693
	DWA KIT B 695	DWA KIT B 695	DIRECT WIRED ALARM 9000 B 695
	DWA KIT B 696	DWA KIT B 696	DIRECT WIRED ALARM 9000 B 696
	DWA KIT B 605	95059503	DIRECT WIRED ALARM 9000 B 605
	DWA KIT B 606	DWA KIT B 606	DIRECT WIRED ALARM 9000 B 606
	DWA KIT B 611	DWA KIT B 611	DIRECT WIRED ALARM 9000 B 611
	DWA KIT B 612	DWA KIT B 612	DIRECT WIRED ALARM 9000 B 612
	DWA KIT B 613	DWA KIT B 613	DIRECT WIRED ALARM 9000 B 613
	DWA KIT B 619	DWA KIT B 619	DIRECT WIRED ALARM 9000 B 619
	DWA KIT B 625	DWA KIT B 625	DIRECT WIRED ALARM 9000 B 625
	DWA KIT B 626	DWA KIT B 626	DIRECT WIRED ALARM 9000 B 626
	DWA KIT B 630	95061784	DIRECT WIRED ALARM 9000 B 630