


PARTS LIST 9600/F9600 SERIES CONCEALED VERTICAL ROD EXIT DEVICE



9600/F9600 SERVICE PARTS LIST (Rev 03-14)

Baloon #	Item #	Part #	DESCRIPTION
1	CHASASSY96	95059600	CHASSIS ASSEMBLY 9600 / F9600 CVR EXIT DEVICE
24	ADJUSTING SCREW	95060360	ADJUSTING SCREW ON 9600/F9600 CHASSIS
2	CHCOV96 PNT	95065680	CHASSIS COVER 9600 / F9600 689/691/693/695/696
2	CHCOV96 605	95065679	CHASSIS COVER 9600 / F9600 605
2	CHCOV96 606	95065681	CHASSIS COVER 9600 / F9600 606
2	CHCOV96 611	95065682	CHASSIS COVER 9600 / F9600 611
2	CHCOV96 612	95065683	CHASSIS COVER 9600 / F9600 612
2	CHCOV96 613	95060380	CHASSIS COVER 9600 / F9600 613
2	CHCOV96 619	95061869	CHASSIS COVER 9600 / F9600 619
2	CHCOV96 625	95065685	CHASSIS COVER 9600 / F9600 625
2	CHCOV96 626	95065686	CHASSIS COVER 9600 / F9600 626
2	CHCOV96 630	95060064	CHASSIS COVER 9600 / F9600 630
3	TBAA689	18002416	TBAR ASSY, 5000/9000 AA 689
3	TBAA695	18002417	TBAR ASSY, 5000/9000 AA 695
3	TBAA696	18002418	TBAR ASSY, 5000/9000 AA 696
3	TBAA691	18002419	TBAR ASSY, 5000/9000 AA 691
3	TBAA693	95071099	TBAR ASSY, 5000/9000 AA 693
3	TBAA605	18002426	TBAR ASSY, 5000/9000 AA 605
3	TBAA606	18002421	TBAR ASSY, 5000/9000 AA 606
3	TBAA611	18002427	TBAR ASSY, 5000/9000 AA 611
3	TBAA612	18002422	TBAR ASSY, 5000/9000 AA 612
3	TBAA613	95071178	TBAR ASSY, 5000/9000 AA 613
3	TBAA619	95061870	TBAR ASSY, 5000/9000 AA 619
3	TBAA625	18002428	TBAR ASSY, 5000/9000 AA 625
3	TBAA626	18002424	TBAR ASSY, 5000/9000 AA 626
3	TBAA630	18002423	TBAR ASSY, 5000/9000 AA 630
3	TBRBB689	18002429	TBAR ASSY, 5000/9000 BB 689
3	TBRBB695	18002430	TBAR ASSY, 5000/9000 BB 695
3	TBRBB696	18002431	TBAR ASSY, 5000/9000 BB 696
3	TBRBB691	18002432	TBAR ASSY, 5000/9000 BB 691
3	TBRBB693	TBRBB693	TBAR ASSY, 5000/9000 BB 693
3	TBRBB605	18002439	TBAR ASSY, 5000/9000 BB 605
3	TBRBB606	18002434	TBAR ASSY, 5000/9000 BB 606
3	TBRBB611	18002440	TBAR ASSY, 5000/9000 BB 611
3	TBRBB612	18002435	TBAR ASSY, 5000/9000 BB 612
3	TBRBB613	18002438	TBAR ASSY, 5000/9000 BB 613
3	TBRBB693	TBRBB693	TBAR ASSY, 5000/9000 BB 619
3	TBRBB625	18002441	TBAR ASSY, 5000/9000 BB 625
3	TBRBB626	18002437	TBAR ASSY, 5000/9000 BB 626
3	TBRBB630	18002436	TBAR ASSY, 5000/9000 BB 630
3A	FTBAA689	18002442	TBAR ASSY, F5000/F9000 AA 689
3A	FTBAA695	18002443	TBAR ASSY, F5000/F9000 AA 695
3A	FTBAA696	18002444	TBAR ASSY, F5000/F9000 AA 696
3A	FTBAA691	18002445	TBAR ASSY, F5000/F9000 AA 691
3A	FTBAA693	FTBAA693	TBAR ASSY, F5000/F9000 AA 693
3A	FTBAA605	18002452	TBAR ASSY, F5000/F9000 AA 605
3A	FTBAA606	18002447	TBAR ASSY, F5000/F9000 AA 606
3A	FTBAA611	18002453	TBAR ASSY, F5000/F9000 AA 611
3A	FTBAA612	18002448	TBAR ASSY, F5000/F9000 AA 612
3A	FTBAA613	18002451	TBAR ASSY, F5000/F9000 AA 613
3A	FTBAA619	FTBAA619	TBAR ASSY, F5000/F9000 AA 619
3A	FTBAA625	18002454	TBAR ASSY, F5000/F9000 AA 625
3A	FTBAA626	18002450	TBAR ASSY, F5000/F9000 AA 626
3A	FTBAA630	18002449	TBAR ASSY, F5000/F9000 AA 630
3A	FTBRBB689	18002455	TBAR ASSY, F5000/F9000 BB 689
3A	FTBRBB695	18002456	TBAR ASSY, F5000/F9000 BB 695
3A	FTBRBB696	18002457	TBAR ASSY, F5000/F9000 BB 696
3A	FTBRBB691	18002458	TBAR ASSY, F5000/F9000 BB 691
3A	FTBRBB693	FTBRBB693	TBAR ASSY, F5000/F9000 BB 693
3A	FTBRBB605	18002465	TBAR ASSY, F5000/F9000 BB 605

9600/F9600 SERVICE PARTS LIST (Rev 03-14)

Baloon #	Item #	Part #	DESCRIPTION
3A	FTBRBB606	18002460	TBAR ASSY, F5000/F9000 BB 606
3A	FTBRBB611	18002466	TBAR ASSY, F5000/F9000 BB 611
3A	FTBRBB612	18002461	TBAR ASSY, F5000/F9000 BB 612
3A	FTBRBB613	18002464	TBAR ASSY, F5000/F9000 BB 613
3A	FTBRBB619	FTBRBB619	TBAR ASSY, F5000/F9000 BB 619
3A	FTBRBB625	18002467	TBAR ASSY, F5000/F9000 BB 625
3A	FTBRBB626	18002463	TBAR ASSY, F5000/F9000 BB 626
3A	FTBRBB630	18002462	TBAR ASSY, F5000/F9000 BB 630
3B	ES TBR AA689	ES TBR AA689	ES TBRASSY,9000 AA 689 (REQUIRES PS501 Power Supply)
3B	ES TBR AA695	95059889	ES TBRASSY,9000 AA 695 (REQUIRES PS501 Power Supply)
3B	ES TBR AA696	ES TBR AA696	ES TBRASSY,9000 AA 696 (REQUIRES PS501 Power Supply)
3B	ES TBR AA691	ES TBR AA691	ES TBRASSY,9000 AA 691 (REQUIRES PS501 Power Supply)
3B	ES TBR AA693	ES TBR AA693	ES TBRASSY,9000 AA 693 (REQUIRES PS501 Power Supply)
3B	ES TBR AA605	ES TBR AA605	ES TBRASSY,9000 AA 605 (REQUIRES PS501 Power Supply)
3B	ES TBR AA606	ES TBR AA606	ES TBRASSY,9000 AA 606 (REQUIRES PS501 Power Supply)
3B	ES TBR AA611	ES TBR AA611	ES TBRASSY,9000 AA 611 (REQUIRES PS501 Power Supply)
3B	ES TBR AA612	ES TBR AA612	ES TBRASSY,9000 AA 612 (REQUIRES PS501 Power Supply)
3B	ES TBR AA613	95057351	ES TBRASSY,9000 AA 613 (REQUIRES PS501 Power Supply)
3B	ES TBR AA619	ES TBR AA619	ES TBRASSY,9000 AA 619 (REQUIRES PS501 Power Supply)
3B	ES TBR AA625	ES TBR AA625	ES TBRASSY,9000 AA 625 (REQUIRES PS501 Power Supply)
3B	ES TBR AA626	95061106	ES TBRASSY,9000 AA 626 (REQUIRES PS501 Power Supply)
3B	ES TBR AA630	95057764	ES TBRASSY,9000 AA 630 (REQUIRES PS501 Power Supply)
3B	ES TBR BB689	95060203	ES TBRASSY,9000 BB 689 (REQUIRES PS501 Power Supply)
3B	ES TBR BB695	95070831	ES TBRASSY,9000 BB 695 (REQUIRES PS501 Power Supply)
3B	ES TBR BB696	ES TBR BB696	ES TBRASSY,9000 BB 696 (REQUIRES PS501 Power Supply)
3B	ES TBR BB691	ES TBR BB691	ES TBRASSY,9000 BB 691 (REQUIRES PS501 Power Supply)
3B	ES TBR BB693	ES TBR BB693	ES TBRASSY,9000 BB 693 (REQUIRES PS501 Power Supply)
3B	ES TBR BB605	ES TBR BB605	ES TBRASSY,9000 BB 605 (REQUIRES PS501 Power Supply)
3B	ES TBR BB606	95057840	ES TBRASSY,9000 BB 606 (REQUIRES PS501 Power Supply)
3B	ES TBR BB611	ES TBR BB611	ES TBRASSY,9000 BB 611 (REQUIRES PS501 Power Supply)
3B	ES TBR BB612	95057702	ES TBRASSY,9000 BB 612 (REQUIRES PS501 Power Supply)
3B	ES TBR BB613	95057249	ES TBRASSY,9000 BB 613 (REQUIRES PS501 Power Supply)
3B	ES TBR BB619	ES TBR BB619	ES TBRASSY,9000 BB 619 (REQUIRES PS501 Power Supply)
3B	ES TBR BB625	18003135	ES TBRASSY,9000 BB 625 (REQUIRES PS501 Power Supply)
3B	ES TBR BB626	95056646	ES TBRASSY,9000 BB 626 (REQUIRES PS501 Power Supply)
3B	ES TBR BB630	95057259	ES TBRASSY,9000 BB 630 (REQUIRES PS501 Power Supply)
3C	ES FTBR AA689	95071169	ES TBRASSY,F9000 AA 689 (REQUIRES PS501 Power Supply)
3C	ES FTBR AA695	95061037	ES TBRASSY,F9000 AA 695 (REQUIRES PS501 Power Supply)
3C	ES FTBR AA696	ES FTBR AA696	ES TBRASSY,F9000 AA 696 (REQUIRES PS501 Power Supply)
3C	ES FTBR AA691	ES FTBR AA691	ES TBRASSY,F9000 AA 691 (REQUIRES PS501 Power Supply)
3C	ES FTBR AA693	ES FTBR AA693	ES TBRASSY,F9000 AA 693 (REQUIRES PS501 Power Supply)
3C	ES FTBR AA605	ES FTBR AA605	ES TBRASSY,F9000 AA 605 (REQUIRES PS501 Power Supply)
3C	ES FTBR AA606	ES FTBR AA606	ES TBRASSY,F9000 AA 606 (REQUIRES PS501 Power Supply)
3C	ES FTBR AA611	ES FTBR AA611	ES TBRASSY,F9000 AA 611 (REQUIRES PS501 Power Supply)
3C	ES FTBR AA612	ES FTBR AA612	ES TBRASSY,F9000 AA 612 (REQUIRES PS501 Power Supply)
3C	ES FTBR AA613	ES FTBR AA613	ES TBRASSY,F9000 AA 613 (REQUIRES PS501 Power Supply)
3C	ES FTBR AA619	ES FTBR AA619	ES TBRASSY,F9000 AA 619 (REQUIRES PS501 Power Supply)
3C	ES FTBR AA625	ES FTBR AA625	ES TBRASSY,F9000 AA 625 (REQUIRES PS501 Power Supply)
3C	ES FTBR AA626	ES FTBR AA626	ES TBRASSY,F9000 AA 626 (REQUIRES PS501 Power Supply)
3C	ES FTBR AA630	95061026	ES TBRASSY,F9000 AA 630 (REQUIRES PS501 Power Supply)
3C	ES FTBR BB689	ES FTBR BB689	ES TBRASSY,9000 BB 689 (REQUIRES PS501 Power Supply)
3C	ES FTBR BB695	ES FTBR BB695	ES TBRASSY,9000 BB 695 (REQUIRES PS501 Power Supply)
3C	ES FTBR BB696	ES FTBR BB696	ES TBRASSY,9000 BB 696 (REQUIRES PS501 Power Supply)
3C	ES FTBR BB691	ES FTBR BB691	ES TBRASSY,9000 BB 691 (REQUIRES PS501 Power Supply)
3C	ES FTBR BB693	ES FTBR BB693	ES TBRASSY,9000 BB 693 (REQUIRES PS501 Power Supply)
3C	ES FTBR BB605	ES FTBR BB605	ES TBRASSY,9000 BB 605 (REQUIRES PS501 Power Supply)
3C	ES FTBR BB606	ES FTBR BB606	ES TBRASSY,9000 BB 606 (REQUIRES PS501 Power Supply)
3C	ES FTBR BB611	ES FTBR BB611	ES TBRASSY,9000 BB 611 (REQUIRES PS501 Power Supply)
3C	ES FTBR BB612	ES FTBR BB612	ES TBRASSY,9000 BB 612 (REQUIRES PS501 Power Supply)
3C	ES FTBR BB613	ES FTBR BB613	ES TBRASSY,9000 BB 613 (REQUIRES PS501 Power Supply)
3C	ES FTBR BB619	ES FTBR BB619	ES TBRASSY,9000 BB 619 (REQUIRES PS501 Power Supply)
3C	ES FTBR BB625	ES FTBR BB625	ES TBRASSY,9000 BB 625 (REQUIRES PS501 Power Supply)
3C	ES FTBR BB626	95056621	ES TBRASSY,9000 BB 626 (REQUIRES PS501 Power Supply)
3C	ES FTBR BB630	95061934	ES TBRASSY,9000 BB 630 (REQUIRES PS501 Power Supply)

9600/F9600 SERVICE PARTS LIST (Rev 03-14)

Baloon #	Item #	Part #	DESCRIPTION
3D	MLR TBR AA689	MLR TBR AA689	MLR TBRASSY,9000 AA 689 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR AA695	MLR TBR AA695	MLR TBRASSY,9000 AA 695 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR AA696	MLR TBR AA696	MLR TBRASSY,9000 AA 696 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR AA691	MLR TBR AA691	MLR TBRASSY,9000 AA 691 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR AA693	MLR TBR AA693	MLR TBRASSY,9000 AA 693 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR AA605	MLR TBR AA605	MLR TBRASSY,9000 AA 605 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR AA606	MLR TBR AA606	MLR TBRASSY,9000 AA 606 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR AA611	MLR TBR AA611	MLR TBRASSY,9000 AA 611 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR AA612	MLR TBR AA612	MLR TBRASSY,9000 AA 612 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR AA613	MLR TBR AA613	MLR TBRASSY,9000 AA 613 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR AA619	MLR TBR AA619	MLR TBRASSY,9000 AA 619 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR AA625	MLR TBR AA625	MLR TBRASSY,9000 AA 625 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR AA626	MLR TBR AA626	MLR TBRASSY,9000 AA 626 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR AA630	MLR TBR AA630	MLR TBRASSY,9000 AA 630 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR BB689	MLR TBR BB689	MLR TBRASSY,9000 BB 689 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR BB695	MLR TBR BB695	MLR TBRASSY,9000 BB 695 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR BB696	MLR TBR BB696	MLR TBRASSY,9000 BB 696 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR BB691	MLR TBR BB691	MLR TBRASSY,9000 BB 691 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR BB693	MLR TBR BB693	MLR TBRASSY,9000 BB 693 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR BB605	MLR TBR BB605	MLR TBRASSY,9000 BB 605 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR BB606	MLR TBR BB606	MLR TBRASSY,9000 BB 606 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR BB611	MLR TBR BB611	MLR TBRASSY,9000 BB 611 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR BB612	MLR TBR BB612	MLR TBRASSY,9000 BB 612 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR BB613	MLR TBR BB613	MLR TBRASSY,9000 BB 613 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR BB619	MLR TBR BB619	MLR TBRASSY,9000 BB 619 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR BB625	MLR TBR BB625	MLR TBRASSY,9000 BB 625 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR BB626	MLR TBR BB626	MLR TBRASSY,9000 BB 626 (REQUIRES PS610 RF Power Supply)
3D	MLR TBR BB630	95069073	MLR TBRASSY,9000 BB 630 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR AA689	MLR FTBR AA689	MLR TBRASSY,F9000 AA 689 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR AA695	MLR FTBR AA695	MLR TBRASSY,F9000 AA 695 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR AA696	MLR FTBR AA696	MLR TBRASSY,F9000 AA 696 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR AA691	MLR FTBR AA691	MLR TBRASSY,F9000 AA 691 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR AA693	MLR FTBR AA693	MLR TBRASSY,F9000 AA 693 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR AA605	MLR FTBR AA605	MLR TBRASSY,F9000 AA 605 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR AA606	MLR FTBR AA606	MLR TBRASSY,F9000 AA 606 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR AA611	MLR FTBR AA611	MLR TBRASSY,F9000 AA 611 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR AA612	MLR FTBR AA612	MLR TBRASSY,F9000 AA 612 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR AA613	MLR FTBR AA613	MLR TBRASSY,F9000 AA 613 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR AA619	MLR FTBR AA619	MLR TBRASSY,F9000 AA 619 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR AA625	MLR FTBR AA625	MLR TBRASSY,F9000 AA 625 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR AA626	MLR FTBR AA626	MLR TBRASSY,F9000 AA 626 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR AA630	MLR FTBR AA630	MLR TBRASSY,F9000 AA 630 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR BB689	MLR FTBR BB689	MLR TBRASSY,9000 BB 689 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR BB695	MLR FTBR BB695	MLR TBRASSY,9000 BB 695 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR BB696	MLR FTBR BB696	MLR TBRASSY,9000 BB 696 (REQUIRES PS610RF Power Supply)
3E	MLR FTBR BB691	MLR FTBR BB691	MLR TBRASSY,9000 BB 691 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR BB693	MLR FTBR BB693	MLR TBRASSY,9000 BB 693 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR BB605	MLR FTBR BB605	MLR TBRASSY,9000 BB 605 (REQUIRES PS610RF Power Supply)
3E	MLR FTBR BB606	MLR FTBR BB606	MLR TBRASSY,9000 BB 606 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR BB611	MLR FTBR BB611	MLR TBRASSY,9000 BB 611 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR BB612	MLR FTBR BB612	MLR TBRASSY,9000 BB 612 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR BB613	MLR FTBR BB613	MLR TBRASSY,9000 BB 613 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR BB619	MLR FTBR BB619	MLR TBRASSY,9000 BB 619 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR BB625	MLR FTBR BB625	MLR TBRASSY,9000 BB 625 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR BB626	MLR FTBR BB626	MLR TBRASSY,9000 BB 626 (REQUIRES PS610 RF Power Supply)
3E	MLR FTBR BB630	MLR FTBR BB630	MLR TBRASSY,9000 BB 630 (REQUIRES PS610 RF Power Supply)
3F	ESSOLPOTBX	95059477	9000 SERIES SOLENOID & POTTING BOX
	PS610RF	33400018	POWER SUPPLY TO BE USED WITH MLR 9000 SERIES EXITS
	PS501	95008619	POWER SUPPLY USED FOR ES 9000 SERIES EXITS
	ES-2	95047135	ADDITIONAL OR REPLACEMENT CARD FOR PS501 POWER SUPPLY

9600/F9600 SERVICE PARTS LIST (Rev 03-14)

Baloon #	Item #	Part #	DESCRIPTION
	ES 105	95003871	POWER TRANSFER RECOMMENDED WITH ES 9000 SERIES EXITS
			Contact factory for availability of C & D length touchbar and rail assemblies. Dogging not available on D bar
4	9ECBRKT	95059476	END CAP MOUNTING PLATE WITH SCREW PACK 9000 (9A)
5	9EC 689	18002285	ENDCAP 9000 689 (Includes Endcap Mounting Bracket & Mounting Screws)
5	9EC 691	18002288	ENDCAP 9000 691 (Includes Endcap Mounting Bracket & Mounting Screws)
5	9EC 693	18002296	ENDCAP 9000 693 (Includes Endcap Mounting Bracket & Mounting Screws)
5	9EC 695	18002286	ENDCAP 9000 695 (Includes Endcap Mounting Bracket & Mounting Screws)
5	9EC 696	18002287	ENDCAP 9000 696 (Includes Endcap Mounting Bracket & Mounting Screws)
5	9EC 605	18002295	ENDCAP 9000 605 (Includes Endcap Mounting Bracket & Mounting Screws)
5	9EC 606	18002290	ENDCAP 9000 606 (Includes Endcap Mounting Bracket & Mounting Screws)
5	9EC 611	18002296	ENDCAP 9000 611 (Includes Endcap Mounting Bracket & Mounting Screws)
5	9EC 612	18002291	ENDCAP 9000 612 (Includes Endcap Mounting Bracket & Mounting Screws)
5	9EC 613	18002294	ENDCAP 9000 613 (Includes Endcap Mounting Bracket & Mounting Screws)
5	9EC 619	18002388	ENDCAP 9000 619 (Includes Endcap Mounting Bracket & Mounting Screws)
5	9EC 625	18002297	ENDCAP 9000 625 (Includes Endcap Mounting Bracket & Mounting Screws)
5	9EC 626	18002293	ENDCAP 9000 626 (Includes Endcap Mounting Bracket & Mounting Screws)
5	9EC 630	18002292	ENDCAP 9000 630 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	F9EC 689	18002298	ENDCAP F9000 689 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	F9EC 691	18002301	ENDCAP F9000 691 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	F9EC 693	18002391	ENDCAP F9000 693 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	F9EC 695	18002299	ENDCAP F9000 695 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	F9EC 696	18002300	ENDCAP F9000 696 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	F9EC 605	18002308	ENDCAP F9000 605 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	F9EC 606	18002303	ENDCAP F9000 606 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	F9EC 611	18002309	ENDCAP F9000 611 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	F9EC 612	18002304	ENDCAP F9000 612 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	F9EC 613	18002307	ENDCAP F9000 613 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	F9EC 619	18002390	ENDCAP F9000 619 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	F9EC 625	18002310	ENDCAP F9000 625 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	F9EC 626	95071296	ENDCAP F9000 626 (Includes Endcap Mounting Bracket & Mounting Screws)
5A	F9EC 630	18002305	ENDCAP F9000 630 (Includes Endcap Mounting Bracket & Mounting Screws)
6	9HSCRPAK	95059919	9H SCREW PACK 9300, 695, 691, 613, 693
6	9ISCRPAK	95059536	9I SCREW PACK 9300 689, 628, 630,626,625
6	9JSCRPAK	95061024	9J SCREW PACK 9300 696, 605, 606
6	9KSCRPAK	95070386	9K SCREW PACK 9300 611, 612
7	DOGKEYPAK	95002638	DOGGING KEY PACK (10 Keys Pack)
8	9GSCRPAK	95059484	9G SCREW PACK CONCEALED VERTICAL ROD
8	96MNTANGL	95060810	MOUNTING ANGLE (INCLUDES 9G SCREW PACK)
8A	9GALD	95060603	ALUMINUM MOUNTING BRACKETS
9	9B CHAS SCRPAK	95059479	96 / 98B SCREW PACK CHASSIS MOUNTING 9600 / 9800
9A	9C F CHAS SCRPAK	95059917	9C SCREW PACK CHASSIS MOUNTING F9600 / F9800
10	418	95059686	TOP STRIKE PACK 9100 / 9600
10A	419	95062118	TOP STRIKE PACK 9100 / 9600 WOOD FRAME
11	NS CVTOPLTCH	95062999	NS TOP LATCH ASSEMBLY 9600
11A	FCVTOPLTCH	95057087	TOP LATCH ASSEMBLY F9100 / F9600
11A	CVTOPLTCH	95065656	TOP LATCH ASSEMBLY 9100 / 9600
11B	CVTOPLTCHELSTRK	95071177	TOP LATCH ASSEMBLY USED WITH ELECTRIC STRIKE
13	439	95059652	STRIKE PACK 9100 / 9600 BOTTOM
17	340	95060489	STRIKE PACK FLAT BOTTOM
15	431	95059565	STRIKE PACK RECESSED BOTTOM

9600/F9600 SERVICE PARTS LIST (Rev 03-14)

Baloon #	Item #	Part #	DESCRIPTION
23	POPPER	95008528	POPPER ASSEMBLY
18	CVRDUPR967	95061649	TOP ROD ASSEMBLY 7FT
18	CVRDUPR968	95061649	TOP ROD ASSEMBLY 8FT
18A	ETR9600	95004847	TOP ROD EXTENDER 2FT ADDITION
22	CVRDLWR96	95060181	BOTTOM ROD ASSEMBLY
19	ROD CLIP	95060469	9600/F9600 ROD RETAINING CLIP
20	NS CVBOTSBLTCH	95062940	NS SLIDE BOLT ASSEMBLY BOTTOM 9600
20	FCVBOTSBLTCH	95056229	SLIDE BOLT ASSEMBLY BOTTOM F9100/ F9600
20A	CVBOTSLBOLT	18002208	SLIDE BOLT ASSEMBLY BOTTOM 9100/9600
21	NS CVBOTPULLTCH	95062940	NS LATCH ASSEMBLY PULLMAN BOTTOM 9100/9600
21	CVBOTPULLTCH	95065652	LATCH ASSEMBLY PULLMAN BOTTOM 9100/9600
21A	FCVBOTPULLTCH	95065658	LATCH ASSEMBLY PULLMAN BOTTOM F9100/F9600
	96CRKT	95065623	CHASSIS REPAIR KIT 9600
	9DRKIT	95052774	DOGGING REPAIR KIT 9000
	MSKIT	95059473	MICRO SWITCH REQUEST TO EXIT KIT
	CD KIT AA 689	95002343	CYLINDER DOGGING KIT 9000 AA 689
	CD KIT AA 691	95002335	CYLINDER DOGGING KIT 9000 AA 691
	CD KIT AA 693	95064816	CYLINDER DOGGING KIT 9000 AA 693
	CD KIT AA 695	95002339	CYLINDER DOGGING KIT 9000 AA 695
	CD KIT AA 696	95002347	CYLINDER DOGGING KIT 9000 AA 696
	CD KIT AA 605	95002353	CYLINDER DOGGING KIT 9000 AA 605
	CD KIT AA 606	95002357	CYLINDER DOGGING KIT 9000 AA 606
	CD KIT AA 611	95002361	CYLINDER DOGGING KIT 9000 AA 611
	CD KIT AA 612	95002365	CYLINDER DOGGING KIT 9000 AA 612
	CD KIT AA 613	95002369	CYLINDER DOGGING KIT 9000 AA 613
	CD KIT AA 619	CD KIT AA 619	CYLINDER DOGGING KIT 9000 AA 619
	CD KIT AA 625	95002373	CYLINDER DOGGING KIT 9000 AA 625
	CD KIT AA 626	95002377	CYLINDER DOGGING KIT 9000 AA 626
	CD KIT AA 630	95002385	CYLINDER DOGGING KIT 9000 AA 630
	CD KIT BB 689	95002345	CYLINDER DOGGING KIT 9000 BB 689
	CD KIT BB 691	95002335	CYLINDER DOGGING KIT 9000 BB 691
	CD KIT BB 693	95064817	CYLINDER DOGGING KIT 9000 BB 693
	CD KIT BB 695	95002341	CYLINDER DOGGING KIT 9000 BB 695
	CD KIT BB 696	95002349	CYLINDER DOGGING KIT 9000 BB 696
	CD KIT BB 605	95002355	CYLINDER DOGGING KIT 9000 BB 605
	CD KIT BB 606	95002359	CYLINDER DOGGING KIT 9000 BB 606
	CD KIT BB 611	95002363	CYLINDER DOGGING KIT 9000 BB 611
	CD KIT BB 612	95002367	CYLINDER DOGGING KIT 9000 BB 612
	CD KIT BB 613	95064815	CYLINDER DOGGING KIT 9000 BB 613
	CD KIT BB 619	CD KIT BB 619	CYLINDER DOGGING KIT 9000 BB 619
	CD KIT BB 625	95002375	CYLINDER DOGGING KIT 9000 BB 625
	CD KIT BB 626	95002379	CYLINDER DOGGING KIT 9000 BB 626
	CD KIT BB 630	95002387	CYLINDER DOGGING KIT 9000 BB 630
	CYL NUT	95060028	CYLINDER NUT
	CYL DOG BRKT	95060488	CYLINDER DOGGING BRACKET
	BPA KIT AA 689	BPA KIT AA 689	BATTERY POWERED ALARM 9000 AA 689
	BPA KIT AA 691	BPA KIT AA 691	BATTERY POWERED ALARM 9000 AA 691
	BPA KIT AA 693	BPA KIT AA 693	BATTERY POWERED ALARM 9000 AA 693
	BPA KIT AA 695	BPA KIT AA 695	BATTERY POWERED ALARM 9000 AA 695
	BPA KIT AA 696	BPA KIT AA 696	BATTERY POWERED ALARM 9000 AA 696
	BPA KIT AA 605	BPA KIT AA 605	BATTERY POWERED ALARM 9000 AA 605
	BPA KIT AA 606	BPA KIT AA 606	BATTERY POWERED ALARM 9000 AA 606
	BPA KIT AA 611	BPA KIT AA 611	BATTERY POWERED ALARM 9000 AA 611
	BPA KIT AA 612	BPA KIT AA 612	BATTERY POWERED ALARM 9000 AA 612

9600/F9600 SERVICE PARTS LIST (Rev 03-14)

Baloon #	Item #	Part #	DESCRIPTION
	BPA KIT AA 613	BPA KIT AA 613	BATTERY POWERED ALARM 9000 AA 613
	BPA KIT AA 619	BPA KIT AA 619	BATTERY POWERED ALARM 9000 AA 619
	BPA KIT AA 625	BPA KIT AA 625	BATTERY POWERED ALARM 9000 AA 625
	BPA KIT AA 626	BPA KIT AA 626	BATTERY POWERED ALARM 9000 AA 626
	BPA KIT AA 630	BPA KIT AA 630	BATTERY POWERED ALARM 9000 AA 630
	BPA KIT BB 689	BPA KIT BB 689	BATTERY POWERED ALARM 9000 BB 689
	BPA KIT BB 691	BPA KIT BB 691	BATTERY POWERED ALARM 9000 BB 691
	BPA KIT BB 693	BPA KIT BB 693	BATTERY POWERED ALARM 9000 BB 693
	BPA KIT BB 695	95057283	BATTERY POWERED ALARM 9000 BB 695
	BPA KIT BB 696	BPA KIT BB 696	BATTERY POWERED ALARM 9000 BB 696
	BPA KIT BB 605	BPA KIT BB 605	BATTERY POWERED ALARM 9000 BB 605
	BPA KIT BB 606	BPA KIT BB 606	BATTERY POWERED ALARM 9000 BB 606
	BPA KIT BB 611	BPA KIT BB 611	BATTERY POWERED ALARM 9000 BB 611
	BPA KIT BB 612	BPA KIT BB 612	BATTERY POWERED ALARM 9000 BB 612
	BPA KIT BB 613	BPA KIT BB 613	BATTERY POWERED ALARM 9000 BB 613
	BPA KIT BB 619	BPA KIT BB 619	BATTERY POWERED ALARM 9000 BB 619
	BPA KIT BB 625	BPA KIT BB 625	BATTERY POWERED ALARM 9000 BB 625
	BPA KIT BB 626	BPA KIT BB 626	BATTERY POWERED ALARM 9000 BB 626
	BPA KIT BB 630	BPA KIT BB 630	BATTERY POWERED ALARM 9000 BB 630
	BPAR KIT AA 689	BPAR KIT AA 689	BATTERY POWERED ALARM 9000 AUTO REARM AA 689
	BPAR KIT AA 691	BPAR KIT AA 691	BATTERY POWERED ALARM 9000 AUTO REARM AA 691
	BPAR KIT AA 693	BPAR KIT AA 693	BATTERY POWERED ALARM 9000 AUTO REARM AA 693
	BPAR KIT AA 695	BPAR KIT AA 695	BATTERY POWERED ALARM 9000 AUTO REARM AA 695
	BPAR KIT AA 696	BPAR KIT AA 696	BATTERY POWERED ALARM 9000 AUTO REARM AA 696
	BPAR KIT AA 605	BPAR KIT AA 605	BATTERY POWERED ALARM 9000 AUTO REARM AA 605
	BPAR KIT AA 606	BPAR KIT AA 606	BATTERY POWERED ALARM 9000 AUTO REARM AA 606
	BPAR KIT AA 611	BPAR KIT AA 611	BATTERY POWERED ALARM 9000 AUTO REARM AA 611
	BPAR KIT AA 612	BPAR KIT AA 612	BATTERY POWERED ALARM 9000 AUTO REARM AA 612
	BPAR KIT AA 613	BPAR KIT AA 613	BATTERY POWERED ALARM 9000 AUTO REARM AA 613
	BPAR KIT AA 619	BPAR KIT AA 619	BATTERY POWERED ALARM 9000 AUTO REARM AA 619
	BPAR KIT AA 625	BPAR KIT AA 625	BATTERY POWERED ALARM 9000 AUTO REARM AA 625
	BPAR KIT AA 626	BPAR KIT AA 626	BATTERY POWERED ALARM 9000 AUTO REARM AA 626
	BPAR KIT AA 630	BPAR KIT AA 630	BATTERY POWERED ALARM 9000 AUTO REARM AA 630
	BPAR KIT BB 689	95059774	BATTERY POWERED ALARM 9000 AUTO REARM BB 689
	BPAR KIT BB 691	BPAR KIT BB 691	BATTERY POWERED ALARM 9000 AUTO REARM BB 691
	BPAR KIT BB 693	BPAR KIT BB 693	BATTERY POWERED ALARM 9000 AUTO REARM BB 693
	BPAR KIT BB 695	95060930	BATTERY POWERED ALARM 9000 AUTO REARM BB 695
	BPAR KIT BB 696	BPAR KIT BB 696	BATTERY POWERED ALARM 9000 AUTO REARM BB 696
	BPAR KIT BB 605	BPAR KIT BB 605	BATTERY POWERED ALARM 9000 AUTO REARM BB 605
	BPAR KIT BB 606	BPAR KIT BB 606	BATTERY POWERED ALARM 9000 AUTO REARM BB 606
	BPAR KIT BB 611	BPAR KIT BB 611	BATTERY POWERED ALARM 9000 AUTO REARM BB 611
	BPAR KIT BB 612	BPAR KIT BB 612	BATTERY POWERED ALARM 9000 AUTO REARM BB 612
	BPAR KIT BB 613	BPAR KIT BB 613	BATTERY POWERED ALARM 9000 AUTO REARM BB 613
	BPAR KIT BB 619	BPAR KIT BB 619	BATTERY POWERED ALARM 9000 AUTO REARM BB 619
	BPAR KIT BB 625	BPAR KIT BB 625	BATTERY POWERED ALARM 9000 AUTO REARM BB 625
	BPAR KIT BB 626	BPAR KIT BB 626	BATTERY POWERED ALARM 9000 AUTO REARM BB 626
	BPAR KIT BB 630	BPAR KIT BB 630	BATTERY POWERED ALARM 9000 AUTO REARM BB 630
	DWA KIT AA 689	DWA KIT AA 689	DIRECT WIRED ALARM 9000 AA 689
	DWA KIT AA 691	DWA KIT AA 691	DIRECT WIRED ALARM 9000 AA 691
	DWA KIT AA 693	DWA KIT AA 693	DIRECT WIRED ALARM 9000 AA 693
	DWA KIT AA 695	DWA KIT AA 695	DIRECT WIRED ALARM 9000 AA 695
	DWA KIT AA 696	DWA KIT AA 696	DIRECT WIRED ALARM 9000 AA 696
	DWA KIT AA 605	DWA KIT AA 605	DIRECT WIRED ALARM 9000 AA 605
	DWA KIT AA 606	DWA KIT AA 606	DIRECT WIRED ALARM 9000 AA 606
	DWA KIT AA 611	DWA KIT AA 611	DIRECT WIRED ALARM 9000 AA 611
	DWA KIT AA 612	DWA KIT AA 612	DIRECT WIRED ALARM 9000 AA 612
	DWA KIT AA 613	DWA KIT AA 613	DIRECT WIRED ALARM 9000 AA 613
	DWA KIT AA 619	DWA KIT AA 619	DIRECT WIRED ALARM 9000 AA 619
	DWA KIT AA 625	DWA KIT AA 625	DIRECT WIRED ALARM 9000 AA 625
	DWA KIT AA 626	DWA KIT AA 626	DIRECT WIRED ALARM 9000 AA 626
	DWA KIT AA 630	DWA KIT AA 630	DIRECT WIRED ALARM 9000 AA 630
	DWA KIT BB 689	DWA KIT BB 689	DIRECT WIRED ALARM 9000 BB 689

9600/F9600 SERVICE PARTS LIST (Rev 03-14)

Baloon #	Item #	Part #	DESCRIPTION
	DWA KIT BB 691	DWA KIT BB 691	DIRECT WIRED ALARM 9000 BB 691
	DWA KIT BB 693	DWA KIT BB 693	DIRECT WIRED ALARM 9000 BB 693
	DWA KIT BB 695	DWA KIT BB 695	DIRECT WIRED ALARM 9000 BB 695
	DWA KIT BB 696	DWA KIT BB 696	DIRECT WIRED ALARM 9000 BB 696
	DWA KIT BB 605	DWA KIT BB 605	DIRECT WIRED ALARM 9000 BB 605
	DWA KIT BB 606	DWA KIT BB 606	DIRECT WIRED ALARM 9000 BB 606
	DWA KIT BB 611	DWA KIT BB 611	DIRECT WIRED ALARM 9000 BB 611
	DWA KIT BB 612	DWA KIT BB 612	DIRECT WIRED ALARM 9000 BB 612
	DWA KIT BB 613	DWA KIT BB 613	DIRECT WIRED ALARM 9000 BB 613
	DWA KIT BB 619	DWA KIT BB 619	DIRECT WIRED ALARM 9000 BB 619
	DWA KIT BB 625	DWA KIT BB 625	DIRECT WIRED ALARM 9000 BB 625
	DWA KIT BB 626	DWA KIT BB 626	DIRECT WIRED ALARM 9000 BB 626
	DWA KIT BB 630	95071206	DIRECT WIRED ALARM 9000 BB 630