

CONFIGURING PSEBH Multi-Tech Reader for BLE



Important! Configuring PSEBH Multi-Tech reader for BLE

Read and follow these instructions:

The Multi-Tech reader ships without customer BLE keys loaded. These keys are customer-specific and are provided by HID. dormakaba does not have access to them.

⚠ CAUTION: HID configuration cards are not provided by BEST. End-users, integrators, or installers should contact their credential provider for details in obtaining HID configuration cards for their site.

How to use Configuration (Config.) cards

- Configurations are loaded during the power-up routine of the ICLASS SE. This can be accomplished using a controller board (BEST electronic locks) that works with the ICLASS SE reader.
- Before powering up, the card must be as close to the reader as possible. Additionally, avoid moving the card for at least 30 seconds.
- When performing this procedure, ensure all cards that may be read by the reader are removed from the vicinity, and any cell phone with an HID app has Bluetooth turned off.
- After applying config. cards, remove the battery in the lock, and reconnect it again to begin using your BLE credential.

⚠ Elite key management is processed in the same manner as BLE config.



For Online Instructions and Translated Material Visit:

<https://dhwsupport.dormakaba.com/hc/en-us>

For Assistance or Warranty Information:

Call 1-800-392-5209 or visit

<https://dhwsupport.dormakaba.com/hc/en-us>