


# Unpacking Instructions for CD517 Capping Press or AD432/3 Key Combinator



## Important! Before unpacking your unit . . .


### . . . read and follow these instructions:

1. Carefully remove the top portion of the foam by placing your hands at opposite ends and gently lifting the foam out. Set the foam aside.
2. Carefully lift the unit out from the bottom portion of the foam.

 **WARNING:** For CD517 capping presses, **DO NOT USE** the geared rack to lift the unit from the carton. Doing so may cause injury.

Only use the handle and the base of the unit to remove it from the carton.

3. After the unit is removed, place the top foam portion back inside the carton. Store the carton and foam for future use.

 **CAUTION:** If the unit is returned for an update or a repair, place the unit inside the plastic bag before repacking in foam.