

Maintenance of 2060/RD2060/RD2068 spring hinges

Surface of any working areas of hinges should be kept clean. Use a soft damp cloth free of any chemicals that would harm the protective lacquer coating. Inspect for locking screw. Replace if removed.

