

Maintenance of DAP-3

Surface and any working area should be kept clean. Use a soft damp cloth free of any chemicals. Inspect all components periodically for mechanical soundness. Retighten fasteners as needed.

