

To maintain your padlock for its maximum life:
Apply one quick spray of BDB60 Corrosion Free
Formula 8000 Industrial Padlock Lubricant and Rust
Inhibitor into both shackle holes every six months.
Note: Spray more often if the padlock is used
frequently or is located in a corrosive environment.

Interchangeable Core Padlock

Notice

Loose throw members are inside. Place the throw member into the core and then the core into the padlock to make the padlock operable. Use a spacer with a 6-pin core. If you fail to use a spacer, the throw member can become disengaged and drop into the core. In that case, the padlock will not function.