

To maintain your padlock for its maximum life:
Apply one quick spray of BD660 *Corrosion Free* Formula 8000 Industrial Padlock Lubricant and Rust Inhibitor into both shackle holes every six months.
Note: Spray more often if the padlock is used frequently or is located in a corrosive environment.

Interchangeable Core Padlock

Notice

Loose throw members are inside. Place the throw members into the core and then the core into the padlock to make the padlock operable.

Use a spacer with a 6-pin core. If you fail to use a spacer, the throw member can become disengaged and drop into the core. In that case, the lock will not function.



a Division of Stanley Security Solutions, Inc.

T80281 Rev A 1815447
ER7991-21 Apr 2006