

**To maintain your padlock for its maximum life:**  
Apply one quick spray of BD660 *Corrosion Free*  
Formula 8000 Industrial Padlock Lubricant and Rust  
Inhibitor into both shackle holes every six months.  
**Note:** Spray more often if the padlock  
is used frequently or is located in  
a corrosive environment.

## Interchangeable Core Padlock

### Notice

Loose throw members are inside. Place the throw member into the core and then the core into the padlock to make the padlock operable. Use a spacer with a 6-pin core. If you fail to use a spacer, the throw member can become disengaged and drop into the core. In that case, the padlock will not function.



a Division of Stanley Security Solutions, Inc.

T80280 Rev A 1815489  
ER7991-21 Apr 2006