EHD9000 IS/ISJ/ISH/ISJH

Surface applied closer Integra stop arm for regular and top jamb mounts with optional hold open [ISH/ISJH]

Installation Instructions



OVERVIEW




Table of contents

1 1.1 1.2 1.3	Technical specifications Overview Tools recommended Handing the door	3 3 3 3
2 2.1 2.2	Instructions - regular mount Securing surface closer and main arm to door Securing main arm to closer	4 4 4
3 3.1 3.2	Instructions - top jamb mount Securing surface closer and main arm to frame Securing main arm to closer	5 5
4	Adjustments	6
4.1 4.2 4.3	Adjusting closing speeds: sweep, latch, backcheck, delayed action Adjusting optional hold open Adjusting spring force	6 6 7
5	Installing covers	8

1 Technical specifications

1.1 Overview



Sex nuts are required for attachment of components to unreinforced doors and to wood or plastic faced composite type fire doors, unless an alternative method is identified in the individual door manufacturer's listings.



Maximum 6-1/2" reveal on top jamb mounts for max openings.



Know the swing of the door which is being installed prior to installation.



Verify closer spring size prior to installation.



Make sure door efficiently operates prior to installing closer.



Do not hammer arm onto spindle. Warranty will be void.



Adjust spring size by hand only. Do NOT use a drill or power tools. Warranty will be void.


1.2 Tools recommended

Table 1

Drill bits:	#3 Phillips screwdriver		
Metal: 7/32" drill bit; #12-24 tap	1/2" or 13mm box wrench		
Wood: 5/32" bit	1 O" adjustable wrench		
DPK: 1/8"	Hex keys: 3mm, 5mm, 3/16"		
Sex nuts: 3/8"			

1.3 Handing the door






2 Instructions - regular mount


2.1 Securing surface closer and main arm to door

Fig.2



2.2 Securing main arm to closer


Fig. 3



3 Instructions - top jamb mount


3.1 Securing surface closer and main arm to frame

Fig. 4



3.2 Securing main arm to closer


Fig.5



4 Adjustments



Confirm closer spring size prior to making any closing speed adjustments.






Maximum opening angle is 110°.

Door should close in 5 to 7 seconds from 90° .

Do not close valves completely.

4.1 Adjusting closing speeds: sweep, latch, backcheck, delayed action


Fig.6



- 3.1.1 Adjust closing sweep speed: 9 0° to start of latch speed.
- Increase sweep speed: Turn valve counter-clockwise.
- Decrease sweep speed: Turn valve clockwise.
- 3.1.2 Adjust closing latch speed: 1.5° to close.
- Increase latch speed: Turn valve counter-clockwise.
- Decrease latch speed: Turn valve clockwise.
- 3.1.3 Adjust opening backcheck: beginning at 8 0°.
- Increase resistance: Turn valve clockwise.
- Decrease resistance: Turn valve counter-clockwise.
- 3.1.4 Adjust closing delayed action: angle 1.80° to 60° .
- Increase delayed action: Turn valve clockwise.
 - Decrease delayed action: Turn valve counter-clockwise.


4.2 Adjusting optional hold open

Fig.7



4.3 Adjusting spring force

Fig. 8






Adjust spring size by hand only. Do NOT use a drill or power tools. Warranty will be void.

NOTICE: EHD9016 is adjustable size 1 through 6. Supplied with a size 3.

NOTE: Barrier free openings:


Take an opening force reading from the pull on the door. If required, adjust the spring force to meet the barrier-free requirement. Depending on opening conditions, a door adjusted to meet barrier-free forces may not have sufficient power to reliably close and latch the door.



Regular and Top jamb mount									
	Closer size	Max door	Door width		Full turns				
	Closer size weig	weight (lbs)	Interior	Exterior	Full turns				
	1	ADA	Ġ.		-55				
	2	100	2'6"		-30				
	3	125	3'	2'6"	0				
EHD9016	4	150	3'6"	3'	+19				
	5	200	4'	3'6"	+37				
	6	250		4'	+52				
	6+	250		4'	+70				

5 Installing covers

Fig.9





For Complete Online Instructions Visit: https://dhwsupport.dormakaba.com/hc/en-us For assistance or warranty information: Call 1-800-392-5209 or visit https://dhwsupport.dormakaba.com/hc/en-us



Para ver las instrucciones en línea, visite: https://dhwsupport.dormakaba.com/hc/en-us Para recibir asistencia o información sobre la garantía: Llame al 1-800-392-5209 o visite https://dhwsupport.dormakaba.com/hc/en-us



Francais

Español

Pour obtenir des instructions complètes en ligne, consultez le site : https://dhwsupport.dormakaba.com/hc/en-us Pour obtenir de l'aide ou des renseignements sur la garantie : Composez le 1-800-392-5209 ou rendez-vous sur le site https://dhwsupport.dormakaba.com/hc/fr-ca