Installation Instructions: Channel Offset Filler



For online instructions, assistance or warranty information: Call 1-800-392-5209 or visit https://dhwsupport.dormakaba.com/hc/en-us

1

Remove cover and endcap, then measure channel and filler. If necessary, cut filler to appropriate length for specific application.



<u>APEX</u>: Loosen chassis mounting screws slightly. If device is not already installed on door, install it and then loosen screws. <u>RELIANT</u>: Skip this step and go to step 9.



L_{FILLER}

Cut <u>only</u> this end of filler to make it the appropriate length.

Do <u>NOT</u> cut notched end!

Filler P/N	Application		L _{FILLER} (in.)	L _{CHANNEL} (in.)
05279-93	APEX	Std. 3 ft.	29-5/16	29-7/32
05286-93	APEX	Std. 4 ft.	41-5/16	41-7/32
NA	APEX	Non-std.	L _{CHANNEL} + 3/32	Variable
NA	RELIANT	Std. 3 ft.	28-11/16	29-7/32
NA	RELIANT	Std. 4 ft.	40-11/16	41-7/32
NA	RELIANT	Non-std.	L _{CHANNEL} – 17/32	Variable

<u>APEX</u>: Remove endcap mounting bracket from door are run in this area, use slack to disengage bracket from channel as best as possible.)



2

3

4

<u>APEX</u>: Insert filler behind channel with single-groove-side against door face and notched end toward hinge.



<u>APEX</u>: Re-install endcap mounting bracket to door, engaging bracket tab into filler notch.



6 APE>

<u>APEX</u>: Re-install device endcap to mounting bracket and re-tighten chassis mounting screws.







Grooves in filler should engage

heads of screws that attach

channel to chassis.

Filler between

channel and

door face.

7 8 APEX: Re-install chassis cover and test device function. APEX: Install retainer screw (only required for devices without a chassis backplate, such as 2300 Series mortise devices). Install screw provided with filler Note: Screw into this opening at is required if back of chassis chassis backplate is assembly. missing! 9 RELIANT: Drill hole through filler, centered across width, for screw attachment to channel. Screw acts as horizontal stop Note: Holes if backplate is not installed. drilled in steps 9 and 10 are different sizes! 1-7/8 Ø 5/32 hole through Notched Width end Backplate missing 21-121

10

<u>**RELIANT</u></u>: Drill hole through channel to receive sheet metal screw. (Device must be removed from door.)**</u>



12

<u>**RELIANT</u>**: Install device to door, engaging endcap mounting bracket tab into filler notch.</u>



<u>**RELIANT</u></u>: Install device endcap and chassis cover, then test device for proper function.</u>**

11

<u>**RELIANT</u>**: Attach filler to channel as shown with sheet metal screw provided.</u>

This space intentionally left blank.

