



Exit Hardware Trim Escutcheon Footprint  
(Looking at door from trim side)

### Notes

- 1 Also see the Q07 Template — *Installation Template for Wi-Q™ Technology EXQ Exit Hardware Trim for Use with Von Duprin 98/99 Series Exit Devices.*
- 2 Allow plus tolerance for clearance per ANSI A115.5. The general tolerance is  $\pm 1/64$ ".
- 3 Use the Von Duprin 98/99 Series exit device installation instructions for backset dimensions.
- 4 Drill all holes completely through.
- 5 Use the Von Duprin 98/99 Series exit device installation instructions to locate the horizontal centerline.
- 6 Hole required for ALL Von Duprin exit devices, however, Von Duprin vertical rod devices and rim devices WITHOUT RQE also require a 1" dia channel (not shown) to this hole from the door edge, aligned on the same horizontal centerline.
- 7 Hole required ONLY for LHRB Von Duprin rim exit devices WITH RQE. Additionally, a 1" dia channel (not shown) to this hole from the door edge, aligned on the same horizontal centerline, is required.
- 8 Hole required ONLY for RHRB Von Duprin rim exit devices WITH RQE. Additionally, a 1" dia channel (not shown) to this hole from the door edge, aligned on the same horizontal centerline, is required.

Title Installation Specification for Wi-Q™ Technology EXQ Exit Hardware Trim for Use with Von Duprin 98/99 Series Exit Devices				BEST ACCESS SYSTEMS		
Series EXQ	Backset See note 3	Trimstyle DV, MS, PM, PH	Door thickness 1 3/4"–2 1/4"	Rev date 02/2017	Template number <b>Q09</b>	Rev <b>B</b>