


*AS REQUIRED TO CLEAR STOP OR HOLDER

FOR 1/4-20 MACHINE SCREWS USE 7/32\" DRILL & TAP
 FOR No.14 WOOD SCREWS USE 5/32\" DRILL
 FOUR (4) HOLES IN FRAME FOR PA BRACKET


NOTES:

1. DO NOT SCALE DRAWING.
2. DIMENSIONS ARE IN INCHES/(MM).
3. LEFT HAND DOOR SHOWN.
4. CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACED COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
5. MAX. OPENING IS 180°.



CAUTION: ALWAYS LOCATE CLOSER FROM SOFFIT BRACKET MOUNTING SURFACE


FOR 1/4-20 MACHINE SCREWS USE 7/32\" DRILL & TAP
 FOR No.14 WOOD SCREWS USE 5/32\" DRILL
 FOR SEX NUTS USE 3/8\" DRILL
 FOUR (4) HOLES IN DOOR FOR CLOSER



DOOR CLOSER MODELS: 7303 - 7305 ARP x PD
 PARALLEL ARM INSTALLATION (PUSH SIDE MOUNT)



DORMA Architectural Hardware
 Reamstown, PA 17567




*AS REQUIRED TO CLEAR STOP OR HOLDER

FOR 1/4-20 MACHINE SCREWS USE 7/32\" DRILL
 FOR No.14 WOOD SCREWS USE 5/32\" DRILL
 FOUR (4) HOLES IN FRAME FOR PA BRACKET

NOTES:


1. DO NOT SCALE DRAWING.
2. DIMENSIONS ARE IN INCHES/(MM).
3. LEFT HAND DOOR SHOWN.
4. CAUTION: SEX NUTS ARE REQUIRED FOR ATTACHMENT OF COMPONENTS TO UNREINFORCED DOORS AND TO WOOD OR PLASTIC FACED COMPOSITE TYPE FIRE DOORS, UNLESS AN ALTERNATIVE METHOD IS IDENTIFIED IN THE INDIVIDUAL DOOR MANUFACTURER'S LISTINGS.
5. MAX. OPENING IS 180°.



FOR 1/4-20 MACHINE SCREWS USE 7/32\" DRILL & TAP
 FOR No.14 WOOD SCREWS USE 5/32\" DRILL
 FOR SEX NUTS USE 3/8\" DRILL
 FOUR (4) HOLES IN DOOR FOR PLATE

CAUTION: ALWAYS LOCATE CLOSER FROM SOFFIT BRACKET MOUNTING SURFACE

PD SOFFIT BRACKET SHOWN ON SOFFIT
 CAN ALSO MOUNT ON FRAME RABBET



DOOR CLOSER MODELS: 7303 - 7305 ARP x PD
 PARALLEL ARM INSTALLATION (PUSH SIDE MOUNT)
 WITH PLATES DP73, DP86



DORMA Architectural Hardware
 Reamstown, PA 17567