





Q Option Upgrade Kit Installation Instructions

QSRK5267 / QSVK5268 Conversion Kits

For online instructions, assistance or warranty information:
Call 1-800-392-5209 or visit <https://dhwsupport.dormakaba.com/hc/en-us>

(1) Disassemble Channel and Touchbar




Note: Hex-dogging rim assembly is shown as example only.

(2) Install Touchbar Switch Assembly and Route Wires

Q Touchbar Switch

Assembly
(wires not shown)



Mount Q Touchbar Switch with 2 screws (#8-32MS) provided. Use plastic washers as spacers in-between the assembly and bracket.

2.1 Mount and adjust Bolt & Nut appropriately for switch activation.

Route harness through 2 holes at either end of subplate as shown and pull it snug.

Position harness in center and tape down underneath subplate.

2.3 Route harness as shown, keeping it clear of lower lip to avoid pinching.

Route harness through switch bracket.

2.2

2.6 (RIM)

*Route harness through wire hole in chassis. Keep clear of moving parts.

(* - If no hole in chassis available, disassemble and drill a thru hole)

VERTICAL
(2203, 2703, 2803)

or
RIM
(2103)

Dress harness clear of lever arm and lower lip to avoid pinching.

2.5

#7 Drill (ø.201") for LHRB device

#7 Drill (ø.201") for RHRB device

.925"


Route harness up through lock side filler as shown. Keep clear of moving parts and cover.

2.6 (VERTICAL)

Note: ELR assembly is shown as example only.

For RIM applications (2103) (3) Install Latchbolt Switch Assembly

Q RIM Latchbolt Switch Assembly (wires not shown)



Note: ELR assembly is shown as example only.

(4) Reassemble device by reversing steps 1.1 to 1.5

Note: Refer to EXQ trim installation instructions for wire connections.

For Vertical applications (2203, 2703, 2803) (3) Install Latchbolt Switch Assembly

Q Vertical Latchbolt Switch Assembly (wires not shown)

