


Caution: Not all holes shown below need to be drilled. Use the diagram AND the chart to determine the holes that you need to drill for your trim and function combination.

Lockset function

	Inside holes							Outside holes						
	Cylinder A 1 1/4" dia.	②	④	⑤	⑥	⑦	①	②	③	④	⑤	⑥	⑦	
A, AW, B, BW, F, FD, FW, HJ		■	■	■	■	■				■	■	■	■	
C, G, INL, IND, W, WW	■		■	■	■	■				■	■	■	■	
E, EW, J			■	■	■	■				■	■	■	■	
HF		■	■	■	■	■		■		■	■	■	■	
L, LF		■	■	■	■	■			■	■	■	■	■	
N, Y			■	■	■	■				■	■	■	■	
P		■			■			■				■		
R	■				■			■				■		
S					■			■				■		
T	■				■			■				■		
2DT				■	■						■	■		
1DT					■							■		



Notes

A Drill a 1 3/4" diameter cylinder hole for 36H and 37H. Use the M escutcheon and the 1E7J4 cylinder to qualify for the UL 437 high security listing. All other escutcheons and roses (with the 1E7K4 cylinder) are available, but do not qualify for the UL 437 high security listing.

B See the H13 Installation Template.

C See the H12 Installation Template.

1 Reference templates H03 and H09 for a complete description of holes.

2 For electrified functions (EWEU, EWEL, etc) see Template W23.

Title
Hole Pattern Chart for 34H-37H Mortise Locks

BEST ACCESS SYSTEMS

Series 34H-37H	Backset 2 3/4"	Trim style A, B, C, D, H, J, M, N, S	Door thickness 1 3/4"-5"	Rev date 06/2003	Template number H04	Rev S
-------------------	-------------------	--	-----------------------------	---------------------	---------------------------	----------